

08/2010 Oversized Jacket

By: burda style magazine

<http://www.burdastyle.com/projects/082010-oversized-jacket>

Oversized Jacket burda style magazine patterns FAQ

Materials

Striped flannel

Step 1 — Preparation

Trace the pattern pieces from the pattern sheet. Trace the facing from piece 1 as a separate pattern piece. Note different lines on back for right and left edges of vent but cut the right and left pieces the same size initially from the double layer of fabric.

Front lining piece: Mark a horizontal line from section seam to point of dart and cut open. Lay vertical dart closed and glue horizontal edges together at bottom end of dart. This creates a bust dart for the lining piece (see pattern layout).

Seam and hem allowances:

Seams and edges 1.5 cm (5/8 in), hem and sleeve hems 4 cm (15/8 ins), no allowance on horizontal edges of centre fronts (scissors symbol) but 1.5 cm (5/8 in) wide allowance at dart. Cut lining pieces with 1.5 cm (5/8 in) seam and hem allowances.

Step 2 — Cutting Out



Flannel:

1â— front 2x

â— â— front facing 2x

2â— back 2x

3â— side piece 2x

4â— back facing, on a fold 1x

5â— collar, on a fold 2x

6â— collar band, on a fold 2x

7â— upper sleeve 2x

8â— undersleeve 2x

a) 4 binding strips, 19 cm (7 1/2 ins) long, 3 cm (1 1/4 ins) wide (incl. allowance),

b) 2 pocket pieces, 19 cm (7 1/2 ins) wide, 19 cm (7 1/2 ins) long (incl. allowance),

c) 4 flap pieces, 15.5 cm (6 1/4 ins) long, 6 cm (2 3/8 ins) wide.

Lining: piece 1 as listed under Preparation ; piece 2 minus neck facing and without vent allowances but at centre back with an ease pleat of about 2 cm (3/4 in); pieces 3, 7 and 8, and also pocket pieces (piece b).

Interfacing: See pattern layout. Interface facing pieces, top collar, flaps, and binding strips with G 785.

Interface remaining shaded pieces and hem allowances with H 410.

Step 3 — Stitch bust darts

Stitch bust darts. Cut close to end of seam at lower horizontal edge of fronts. Press dart allowances open, pressing points of darts flat. Lay horizontal edges of fronts together and baste together with herringbone stitch. Stitch side pieces to fronts. Press seam allowances open.

Step 4 — Bound pockets with flaps

Mark an abutting line for binding, 7 mm (1/4 in) from joining lines (= finished width of binding). Hand baste along these lines to make them visible on right side of fabric. Fold binding strips lengthwise and press, wrong side facing in. Lay doubled binding strips on front and side pieces and pin so that fold edges of binding meet abutting lines. Stitch binding in place along joining lines, 7 mm (1/4 in) from fold edges. Slash between lines of stitching and clip diagonally toward ends of seams, but do not cut into binding. Press binding into pocket openings. Fold small fabric triangles at pocket opening ends to inside and stitch to binding, across base of each. Stitch each interfaced flap piece to flap piece with no interfacing, right sides together, rounding off corners. Leave joining edge open. Trim seam allowances. Turn flaps right side out and press. Slip joining edge of flaps to inside, through pocket openings, and stitch to seam allowances, close to upper binding joining seam. Stitch pocket lining pieces to seam allowances of lower binding and stitch fabric pocket pieces to seam allowances of flaps and upper binding. Trim pocket pieces even and stitch together.

Step 5 — Centre back seam and vent

Stitch centre back seam from upper edge to vent marking. Clip seam allowance of right centre back piece diagonally into corner at top of vent. Press centre seam open. Press edges of back vent under, noting different lines for right and left edges of vent. Trim facing on left edge of vent to 5 cm (2 ins) wide. Topstitch left centre back piece diagonally at top of vent, as marked, catching underlap.

Step 6 — Notched collar and front edges

Pin facing right sides together with jacket. Build a little extra fullness into corners of lapels. Stitch facing to hem edges, front edges, and edges of lapels, to marking. Leave facing lying right sides together with jacket for now. Stitch collar band pieces to collar pieces. Trim seam allowances. Press seams open. Topstitch close to each side of seams. Stitch collar pieces together on outer edges, building a little extra fullness into top collar. Begin and end stitching in front, exactly on seam line of joining edge. Turn collar right side out. Lay collar between jacket and facing. Stitch undercollar to neck edge of jacket and stitch top collar to facing. Press seam allowances of collar joining seams open. Turn facing to inside. Pin collar joining seams together

exactly. Lay back facing up and stitch seam allowances together, close to collar joining seam. Lay back facing down.

Step 7 — Vent facings

Unfold back vent facings at hem. Press hem allowance to inside and sew in place by hand. Lay vent facings to inside again and sew in place over hem.

Step 8 — Sleeves

Stitch front and back sleeve seams. Hem sleeves.

Step 9 — Set in sleeves, easing sleeve caps

Set in sleeves, easing sleeve caps. Lay strips of batting, about 5 cm (2 ins) wide, under sleeve caps and sew to seam allowances. Sew shoulder pads in place.

Step 10 — Jacket lining

Stitch allowances of centre seam of centre back lining together, 1 cm (3/8 in) above vent. For the ease pleat, stitch along centre back at top and bottom (above vent), each about 5 cm (2 ins) long, and baste in between. Press pleat and allowances on edges of vent onto left back piece. Stitch darts and seams of lining. Set in sleeve linings. Stitch lining to inside edges of facing, leaving about 8 cm (3 1/4 ins) open at the bottom. Lay lining inside jacket with wrong sides facing, pulling linings into sleeves. Turn in lining at back vent and pin to facing of right back piece. Trim other edge of lining to 1 cm (3/8 in) before pressed edge of underlap. Clip 1 cm (3/8 in) diagonally into top corner. Turn in edge of lining and pin to vent facing of left back. Pin lining at top of vent to underlap. Pin a fold, about 1 cm (3/8 in) deep, in lining, above jacket hem and sleeve hems. Turn in lining and sew to hem allowances by hand. Remove pins, lay extra length of lining down and press. In front, sew open edges of lining in place. Sew lining to back vent.

BurdaStyle

08/2010 Oversized Jacket