

10/2010 Long leather jacket with front zipper

By: burda style magazine

<http://www.burdastyle.com/projects/102010-long-leather-jacket-wit>



Long leather jacket with front zipper burda style magazine patterns FAQ

Materials

matelassÃ©

Step 1 — Preparation

Trace the pattern pieces from the pattern sheet. Follow lines and details for style 139. Trace pocket piece from piece 1 as a separate pattern — piece — it is the same for all sizes.

Seam and hem allowances:

Seams and edges 1.5 cm (5/8 in), hem and sleeve hems 4 cm (15/8 ins), lining 1.5 cm (5/8 in).

Step 2 — Cutting out



Matelassé©:

1 — centre front 2x

2 — pocket piece 2x

3 — side front 2x

4 — centre back 2x

5 — side back 2x

7 — front sleeve piece 2x

8 — back sleeve piece 2x

9 — front facing 2x

10 — back facing, on a fold 1x

a) underlap, 63 — 63 — 68 — 68 — 68 cm (243/4 — 243/4 — 263/4 — 263/4 — 263/4 ins) long, 6 cm (21/2 ins) wide, finished width 3 cm (11/4 ins).

Leather:

5 — front yoke 2x

6 — back yoke 2x

Lining: pieces 1, 5 and 6 minus width of facing; piece 3 minus neck facing and with an ease pleat of about 2

cm (3/4 in) at centre back; pieces 2, 4, 7, and 8; and also pocket piece (piece 1).
Interfacing: See pattern layout. Also interfacing hem allowances.

Step 3 — Stitch bust darts.

Press up. Stitch front section seams, but do not stitch across pocket openings. In-seam pockets. Stitch pocket lining pieces to centre fronts and stitch pocket pieces of main fabric to side fronts.

Step 4 — Back seam

Stitch centre back seam, leaving vent open at bottom. Clip seam allowance of left centre back diagonally into top corner of vent. Stitch back section seams and side seams. Press allowances open.

Step 5 — Sleeves

Stitch back sleeve seams (seam number 4). Stitch shoulder seams of yokes. Stitch yokes to upper edges of sleeve pieces. Stitch front sleeve seams. Press sleeve hem allowances to inside and sew in place by hand.

Step 6 — Armholes and yokes

Stitch front yokes to fronts then stitch sleeves to edges of armholes and back yokes to back piece. Press seam allowances onto fronts and back, from neck edge to beginning of underarm curve.

Step 7 — Front edges with zip

Open zip. Lay halves of zip face down on seam allowances of front edges (right fabric side) so that zip teeth lie 1.5 cm / 5/8 in (width of seam allowances) from edge. Stitch along middle of zip tapes at a long stitch setting. Fold underlap lengthwise, right side facing in. Stitch across top and bottom ends. Turn underlap right side out and press. Lay underlap on left front, over zip tape, 5 mm (3/16 in) from edge of seam allowance. On front edge of each front facing, trim away 7 mm (1/4 in) from edge of seam allowance and mark a new seam line 7 mm (1/4 in) from original line. Lay facings right sides together with fronts and glue to edge of zip tapes, with glue stick and baste to underlap. On inside of fronts, stitch along zip joining seam then stitch up to the hem edge. Lay front facings forward over joining seam and press. Press hem allowance to inside but do not yet sew. Lay front facings and seam allowances on front edges, with zip, to inside. Press front edges. Topstitch 7 mm (1/4 in) from front edges (zipper foot).

Do not glue underlap in place, but baste instead.

Step 8 — Neck edge

Stitch back facing to shoulder edges of front facings. On front edges, lay seam allowances with zip outward and pin to neck edge, then pin facing along neck edge. Stitch along neck edge. Trim seam allowances. Lay facing up at neck edge and stitch to seam allowances, as far as possible, next to seam. Turn facing to inside. Press edges. Sew shoulder pads in place.

Step 9 — Vent

Press vent facing on right back to inside. Narrowly hem vertical edge of underlap on left back. Topstitch right centre back at top of vent as marked, catching underlap.

Step 10 — Gems

Sew — gems — to yokes as illustrated or as desired.

Step 11 — Sew lining

On centre back lining pieces, stitch allowances of centre seam together above vent, stitching 1 cm (3/8 in) from edge. For the ease pleat, stitch along centre back at top and bottom (above vent), each about 5 cm (2 ins) long, and baste in between. Press pleat and vent allowances onto left back. Stitch darts and remaining seams of lining. Set in sleeve linings.

Step 12 — Line jacket

Stitch lining to inside edge of facing, leaving about 7 cm (3 ins) open at bottom. Lay lining inside jacket, with wrong sides facing, pulling linings into sleeves. At back vent, turn in lining at edge of underlap on left back and pin. Trim other edge of lining to 1 cm (3/8 in) before hemmed edge of underlap. Clip 1 cm (3/8 in) diagonally into top corner. Turn in edge of lining and pin to vent facing of right back. Turn in lining and pin to underlap at top of vent. Pin a fold in lining about 1 cm (3/8 in) deep above jacket hem. Turn in lower edge of lining and sew to hem allowance. Lay extra length of lining down and press lightly. Sew remaining front edges of lining to facing. Sew lining to back vent. Turn in sleeve linings and sew to hem allowances. Lay extra length of lining down and press.

BurdaStyle

10/2010 Long leather jacket with front zipper