

08/2010 Standing Collar Coat

By: burda style magazine

<http://www.burdastyle.com/projects/082010-standing-collar-coat>

Standing Collar Coat burda style magazine patterns FAQ

Materials

duvetyne

Step 1 — Preparation

Trace the pattern pieces from the pattern sheet. Follow lines and details for style 111. Lengthen pieces 2, 3 and 7 as indicated. Note different lines on centre back piece for right and left edges of vent but first cut the right and left pieces the same size from the double layer of fabric.

The buttonhole on piece 1 is marked for size 36. Remark the buttonhole for the other sizes according to the size lines. The buttonhole on piece 4 is marked for size 36. Remark the buttonhole for the other sizes according to the size lines.

Seam and hem allowances:

Seams and edges 1.5 cm (5/8 in), hem and sleeve hems 4 cm (15/8 ins), lining 1.5 cm (5/8 in).

Step 2 — Cutting out



Duvetyne:

1— 1 front 2x

2— 2 centre back 2x

3— 3 side back 2x

4— 4 upper sleeve 2x

5— 5 undersleeve 2x

6— 6 standing collar, on a fold 2x

7— 7 front facing 2x

8— 8 back facing, on a fold 1x

9— 9 flap 2x

10— 10 upper left welt 1x

11— 11 pocket piece

12— (upper left pocket) 1x

a) 4 binding strips (lower pockets), 21 1/2" — 21" — 21.5" — 21.5" — 22 cm (83/8" — 83/8" — 81/2" — 81/2" — 83/4 ins) long, 3 cm (1 1/4 ins) wide (incl. allowance),

b) 2 pocket pieces (lower pockets), 21 1/2" — 21" — 21.5" — 21.5" — 22 cm (83/8" — 83/8" — 81/2" — 81/2" — 83/4 ins) wide, 21 cm (8 3/8 ins) long (incl. allowance).

Lining: piece 1 to lining line; piece 2 minus neck facing, without vent allowance and at centre back with an ease pleat of about 2 cm (3/4 in); 12—piece 4 without vent allowance; pieces 3, 5, 9 and 11; and also pocket piece (b).

Interfacing: See pattern layout. Iron strips of interfacing, about 3 cm (1 1/4 ins) wide, to wrong side of fabric, over pocket markings. Also interface hem allowances. Iron Vilene Bias Tape to neck and armhole edges.

Step 3 — Darts

On front pieces, cut along centre of each side dart to about 7 cm (2¾ ins) before point. Stitch side front darts. Trim dart allowances to 1 cm (3/8 in) wide and press open, pressing points of darts flat. Stitch darts in neck edge and press toward centre. Stitch side seams (seam number 4).

Step 4 — Bound pockets with flaps

Mark abutting lines for binding 7 mm (1/4 in) from joining lines for binding (= finished width of binding). Hand baste along these lines to make them visible on right side of fabric. Fold binding strips lengthwise and press, wrong side facing in. Lay doubled binding strips on front and back pieces so that fold edges of binding meet abutting lines. Stitch binding along joining lines, stitching 7 mm (1/4 in) from fold edges. Slash between lines of stitching and clip diagonally toward ends of seams. Do not cut into binding. Press binding into pocket openings. Fold small fabric triangles at pocket opening ends to inside and stitch to binding, from seam end to seam end. Stitch pocket lining pieces to seam allowances of lower binding joining seams and press down. Lay each interfaced flap piece on flap piece with no interfacing, right sides together. Stitch side and lower edges together. Trim seam allowances. Turn flaps right side out and press. Slide flaps through pocket openings to inside and stitch to seam allowances, close to upper binding joining seams. Pin fabric pocket pieces to seam allowances of flaps. Work from side of upper binding seam allowance to stitch close to seam. Trim pocket pieces even and stitch together.

Step 5 — Sew welt pocket at top of left front

Fold welt lengthwise, with right side facing in. Stitch across ends. Turn welt right side out. Stitch welt right sides together with front, along joining line, with welt pointing down. Lay fabric pocket piece on front, opposite welt, and stitch 1 cm (3/8 in) from welt joining seam. This seam should be about 5 mm (3/16 in) shorter at both ends than the welt joining seam. Slash between lines of stitching and clip diagonally toward ends of seam. Do not cut into pocket pieces. Pull pocket pieces to inside and press welt over pocket opening. Work from inside to stitch pocket lining to seam allowances of welt joining seam. Fold small triangles at pocket opening ends to inside and sew to pocket piece. Trim pocket pieces even and stitch together. Edgestitch narrow edges of welt in place. Sew narrow edges of welts in place by hand.

Step 6 — Vent

Stitch centre back seam from upper edge to vent marking. Clip seam allowance of right centre back piece diagonally into corner at top of vent. Press centre seam open.

Step 7 — Vent

Press edges of back vent to inside, noting different lines for right and left edges of vent. Trim facing on left edge of vent to 5 cm (2 ins) wide. At top of vent, topstitch left centre back piece diagonally as marked, catching underlap.

Step 8 — Seams

Stitch back section seams, shoulder seams, and facing seams.

Step 9 — Buttonholes

Work buttonholes in right front facing. Pin facing right sides together with coat. Stitch along front edges and edges of lapels, to marking. Leave facing lying right sides together with coat for now.

Step 10 — Standing collar

Lay collar pieces right sides facing. Stitch together on front and upper edges, beginning and ending stitching in front, exactly on seam line. Trim seam allowances. Turn collar right side out and press. Lay collar between jacket and facing. Stitch outer collar piece to neck edge of jacket and stitch inside collar piece to facing. Press seam allowances open. Turn facing to inside. Pin collar joining seams together. Lay facing in back up again and stitch seam allowances together, close to collar joining seam. Lay facing down.

Step 11 — Two-piece sleeve with vent

Stitch front sleeve seams. Lay vent facing and hem allowance of upper sleeves outward and mitre the corner with a diagonal seam. Trim allowances of mitred seam to 5 mm (3/16 in) and press open. Stitch hem allowance of undersleeve pieces to lengthwise edge of underlaps. Turn hem allowances and front vent facings to inside. Press edges of hem and vents to inside and also press allowances on long edges of underlaps to inside. Stitch back sleeve seams exactly to vent mark. Press seam allowances open and press allowances onto upper sleeves, toward top of vent. Sew top ends of facing and underlap together.

Step 12 — Sleeves

Set in sleeves, easing sleeve caps.

Step 13 — Hem

Unfold front facings and back vent facings at hem. Press hem allowance to inside and sew in place by hand. Lay vent facings to inside again and sew in place over hem.

Step 14 — Coat lining

Stitch allowances of centre seam of centre back lining together, 1 cm (3/8 in) above vent. For the ease pleat, stitch along centre back at top and bottom (above vent), each about 5 cm (2 ins) long, and baste in between. Press pleat and allowances on edges of vent onto left back piece. Stitch darts and seams of lining. Set in sleeve linings. Stitch lining to inside edges of facing, leaving about 8 cm (3 1/4 ins) open at the bottom. Lay lining inside coat with wrong sides facing, pulling linings into sleeves Turn in lining at back vent and pin to facing of right back piece. Trim other edge of lining to 1 cm (3/8 in) before pressed edge of underlap. Clip 1 cm (3/8 in) diagonally into top corner. Turn in edge of lining and pin to vent facing of left back. Pin lining at top of vent to underlap. Pin a fold, about 1 cm (3/8 in) deep, in lining, above coat hem and sleeve hems. Turn in lining and sew to hem allowances by hand. Remove pins, lay extra length of lining down and press. In front, sew open edges of lining in place. Sew lining to back vent.

Step 15 — Sew sleeve linings in place

At top of vent on one sleeve, pin seam of lining to sleeve seam, pushing lining up slightly. At vent, turn back lining which lies on top. Turn under lining which lies below and pin to underlap edge of undersleeve. Lay turned-back lining over vent, trim to 1 cm (3/8 in) before edge of underlap, trim away 1 cm (3/8 in) below end of vent, and clip diagonally about 1 cm (3/8 in) long into corner. Turn in lining and pin to vent facing of upper sleeve and to underlap at top of vent. Turn in lower edge of lining and pin to hem allowance. Sew lining in place. Sew lining of other sleeve in same manner.

Step 16 — Buttonholes

Work diagonal buttonhole in right front. Sew on buttons to match buttonholes. Sew one button each to sleeve vents, catching underlaps. Stitch thread bars, about 1 cm (3/8 in) long, 5 cm (2 ins) from right front edge and centred between buttonholes on facing and also 5 cm (2 ins) above top buttonhole and below bottom buttonhole.

BurdaStyle

08/2010 Standing Collar Coat