

09/2011 Velvet Jacket Plus Size

By: burda style magazine

<http://www.burdastyle.com/projects/092011-velvet-jacket-plus-size>



Velvet Jacket plus size sewing pattern. burda style magazine patterns FAQ

Materials

Cotton velvet

Step 1 — Preparation



Paper cut for ANSI A (German DIN A4) prints:

This pattern is printed on 8.5 × 11 sheets of plain paper. Do not scale or center pages before printing. Wait until all sheets are printed out before beginning to tape them together. **Do not cut out pattern pieces yet**— Arrange the sheets on a large, hard, flat surface so that they fit together, matching up like numbers and letters (i.e. 6A to 6A). To tape pattern together, fold under the margin of one piece (6A) and tape right against the line of it's matching number/letter (6A).

burda style magazine pattern do not have seam allowance included.

Seam and hem allowances to be added: Seams and edges 1.5 cm (5/8 in).

see example here: <http://www.burdastyle.com/projects/072011-jumpsuit/instructions/1>

Step 2 — Cutting out



Velvet:

21centre front 2x

22side front 2x

23upper centre back 2x

24lower centre back 2x

25pleat underlay 1x

26side back 2x

27upper sleeve 2x

28under sleeve 2x

29standing collar, on a fold 2x

30back facing, on a fold 1x

Lining: pieces 21, 27, and 28 minus width of facing; pieces 23 and 24 placed together, minus neck facing and with an ease pleat of approx. 2 cm (3/4 in) at centre back; also pieces 22 and 26.

Interfacing: See pattern layout. Also interface hem allowances.

Step 3 — Back

Stitch centre seam on upper centre back. Press seam allowances open.

Step 4 — Mitre the corners

Lay the lower centre back pieces right sides together and stitch the centre seam from the upper edge to the marking. Press the seam allowances open. Mitre the corners of the hem on lower centre back: Turn the self-facings at centre back and the hem allowances to outside and stitch diagonally to mitre the corners. Trim the allowances of mitring seams to 5 mm (3/16 in) wide and press open. Turn facings and hem allowances to inside.

Lay the lower centre back on the pleat underlay and baste together on side and upper edges. The hem allowance of the pleat underlay extends at the lower edge.

Step 5 — Back

Stitch the upper centre back to the lower centre back. Press the seam allowances up. Stitch the front and back section seams. Stitch side seams, shoulder seams, and facing seams. Press the seam allowances open.

Step 6 — Standing collar, lapels, and front edges

Lay the collar pieces right sides together. Stitch along the front and upper edges, beginning and ending stitching in front, exactly on the seam line of the joining edge. Trim the seam allowances. Turn the collar right side out and press. Pin the facing right sides together with the jacket. Stitch along the front edges and edges of lapels, up to seam marks. Leave the facing lying right sides together with the jacket for now. Lay collar between the jacket and the facing. Stitch outer collar piece to the neck edge of jacket and stitch the inside collar piece to the facing. Press the seam allowances open. Turn the facing to the inside. Pin the collar joining seams together exactly. Turn the back facing up and stitch the seam allowances together, close to the collar joining seam. Turn facing down.

Step 7 — Facings

At hem edge, unfold the facings. Press the hem allowance to inside but do not yet sew in place.

Step 8 — Sleeves

Stitch the front sleeve seams, also on the facings. Pin the sleeve facings right sides together with lower edges of sleeves. Stitch along edges of sleeve vents, from slit mark, and along hem edges. Turn upper edge of facings back at ends of seams and pin. Stitch back sleeve seams to slit mark. Remove the pins. Stitch facing seams. Turn facings to inside. Press edges of hem and sleeve vents.

Step 9 — Sleeve caps

Set in sleeves, easing sleeve caps. Sew shoulder pads in place.

Step 10 — Sew lining

On centre back lining pieces, stitch allowances of centre seam together, 1 cm (3/8 in) from edge. For the ease pleat, stitch along centre back, approx. 5 cm long, at upper and lower edges, and baste in between. Press pleat to one side. Stitch seams of lining. Set in sleeve linings.

Step 11 — Line jacket, hem jacket

Stitch lining to inside edges of facing, turning hem allowance of facings down. Lay lining inside jacket with wrong sides together, pulling linings into sleeves. Turn hem allowance to inside and sew in place by hand. Turn in lining along lower edge of jacket. Press fold edge lightly, push upward in a shallow curve, and pin to hem allowance. Sew facings and lining in place. Lay extra length of lining down and press lightly. Turn in edges of sleeve linings and sew to hem allowance. Turn in sleeve linings and sew to facings.

Step 12 — Hook

Lay front edges together at waist level and fasten with a hook and eye. Sew one hook and eye to top end of each sleeve vent.

BurdaStyle

09/2011 Velvet Jacket Plus Size