

10/2011 Printed 70s Wrap Dress

By: burda style magazine

<http://www.burdastyle.com/projects/102011-printed-70s-wrap-dress>



Wrap dress burda style magazine patterns FAQ

Materials

Print crpe chiffon

Step 1 — Preparation



Paper cut for ANSI A (German DIN A4) prints:

This pattern is printed on 8.5 × 11 sheets of plain paper. Do not scale or center pages before printing. Wait until all sheets are printed out before beginning to tape them together. **Do not cut out pattern pieces yet**— Arrange the sheets on a large, hard, flat surface so that they fit together, matching up like numbers and letters (i.e. 6A to 6A). To tape pattern together, fold under the margin of one piece (6A) and tape right against the line of it's matching number/letter (6A).

burda style magazine pattern do not have seam allowance included.

Seam and hem allowances to be added: Seams and edges 1.5 cm (5/8 in).

see example here: <http://www.burdastyle.com/projects/072011-jumpsuit/instructions/1>

Step 2 — Cutting out



Print chiffon:

1 front 2x

3 back, on a fold 1x

4 front facing 2x

5 back facing, on a fold 1x

6 sleeve 2x

a) 2 tie bands 120 — 124 — 128 — 132 — 136 cm (47 1/4 — 49 — 50 1/2 — 52 — 53 1/2 ins) long, 8 cm (3 1/4 ins) wide, finished width 4 cm (1 5/8 ins).

Plain chiffon (lining): pieces 1 and 3.

Interfacing: See pattern layout.

Step 3 — Bust darts

Stitch bust darts. Press darts down. Work from inside to stitch pleats in fronts and in back, between arrow marks. Lay pleats in direction of arrows. Press pleat seams.

Step 4 — Slit

Stitch the side seams. Leave slit open in right side seam. Trim seam and slit allowances to 7 mm (1/4 in) wide. Clip the seam allowances of the fronts at ends of slit. Neaten the slit allowances and press to the inside. Above and below the slit, neaten the seam allowances together and press onto the back.

Step 5 — Facings

Stitch the shoulder seams. Neaten the seam allowances together and press onto the back. Stitch the shoulder seams of the facing. Press the seam allowances open. Neaten inside edge of facing.

Step 6 — Hem

Press hem allowance to inside, turn in, and stitch.

Step 7 — Tie bands

Fold tie bands lengthwise, right side in. Trim one end of each at an angle. Stitch along the long edge and the angled end. Trim the seam allowances. Turn the bands right side out and press. Baste the bands to the front edges, between the markings, over the flounce.

Baste tie bands to front edges, below neck edge.

Step 8 — Lining

Sew the lining as for the dress. Turn in hem allowance of lining and stitch so that lining is 2 cm (3/4 in) shorter than dress. Baste facing to front and neck edges of dress lining, with wrong side facing right side — lower facing edges extend past lining hem. Stitch inside facing edge in place. Lay lining with facing right sides together with dress. Stitch along front and neck edges, catching tie bands. Trim seam allowances. Turn lining with facing forward and up and stitch to seam allowances, close to seam. Turn lining with facing to inside and press edges. Turn in lower facing edges and sew to the hem edge. At edges of slit in right side seam, turn lining edges under and baste. Topstitch close to edges of slit. Baste lining to armhole edges.

Step 9 — Sleeves

Stitch the sleeve seams, leaving seam open below hem line, to insert elastic. Press sleeve hem allowances to inside, turn in, and stitch as marked to form elastic casing. Pull elastic into casings. Sew ends of each elastic together to a circumference of 19 — 20 — 21 — 22 — 23 cm (7 1/2 — 8 — 8 3/8 — 8 3/4 — 9 1/8 ins).

Step 10 — Sleeve caps

Set in sleeves, easing sleeve caps. Set in sleeves, easing sleeve caps.

BurdaStyle

10/2011 Printed 70s Wrap Dress