

07/2010 Leather Jacket

By: burda style magazine

<http://www.burdastyle.com/projects/072010-leather-jacket>

Leather Jacket burda style magazine patterns FAQ

Materials

Lamb nappa leather

Step 1 — Preparation

Trace the pattern pieces from the pattern sheet. Trace piece 5 twice. Cut one piece apart on the marked seam line for the top collar. The zip lines on pieces 7 and 8 are marked for size 36. For sizes 38 — 44, mark the lines the same distance from the corresponding size lines. The buttonhole on piece 1 is marked for size 36.

For the other sizes, move the buttonhole forward, the same distance from the corresponding size lines.

Seam and hem allowances:

Seams and edges 1.5 cm (5/8 in), hem (pieces 2, 4 and 9) 4 cm (1 5/8 ins), sleeve hems 6 cm (2 3/8 ins) (flare sleeve hem allowances). Cut lining pieces with 1.5 cm (5/8 in) seam and hem allowances.

Step 2 — Cutting out



Lamb nappa leather:

1 centre front 2x

and as facing 2x

2 side front 2x

3 centre back, on a fold 1x

4 side back 2x

5 top collar, divided each 2x

5 under collar 2x

6 back facing, on a fold 1x

7 upper sleeve 2x

8 under sleeve 2x

9 back peplum, on a fold 1x

Lining: piece 3 minus neck facing and at centre back with an ease pleat of about 2 cm (3/4 in); pieces 4 and 9 without pleat; pieces 2, 7 and 8.

Interfacing: Interface centre and side fronts, under collar pieces, back facing and hem allowances. Do not interface hem allowance of peplum. Iron shaped strips of interfacing, about 2 cm (3/4 in) wide, to edges of armholes.

Step 3 — Centre Front

Stitch right side front to right centre front. Topstitch centre front close to seam.

Step 4 — Separate zip

Lay left half of zip face up on side edge of left centre front, between markings, so that teeth of zip lie on garment piece and tape of zip lies on seam allowance. Turn in top end of zip tape toward seam allowance. Stitch zip tape to seam allowance.

Step 5 — Stitch left side front to left centre front, catching the zip

Clip seam allowance of side front at top of zip, close to stitching. Lay seam allowances above zip onto centre front. Topstitch centre piece close to edges. Lay seam allowances at zip and below onto side front. Topstitch side piece.

Step 6 — Section Seams

Stitch section seams on top collar pieces. Topstitch 7 mm (1/4 in) to each side of seams. Stitch each top collar piece to undercollar piece, along outer edge, right sides together. Trim seam allowances. Turn collar right side out and topstitch close to edges. Lay joining edges of collar together on neck edge of front, between markings, and stitch to seam allowance. Stitch upper narrow edges of collar to shoulder seam allowances of fronts.

Step 7 — Back peplum

Stitch side backs to centre back, from upper edge to corner. Clip seam allowance of side back pieces into corners. Fold pleats in back peplum in arrow direction and press. Sew to seam allowance of upper edge. Fold side edges of back peplum piece to inside on fold line and hold in place with paper clips. Lay peplum on side back pieces, with fold at abutting line. Stitch inside pleat seams (seam number 3) to about 10 cm (4 ins) above hem. Stitch centre back to back peplum piece. Topstitch centre back close to vertical section seams and horizontal seam.

Step 8 — Side seams

Stitch side seams. Spread seam allowances apart and glue down (textile adhesive). Stitch shoulder seams. Topstitch back close to shoulder seams

Step 9 — Zip

Lay other half of zip face down on right front edge (right side of leather), to marking, so that teeth of zip lie on garment piece and zip tape lies on seam allowance. Fold top end of zip tape down. Stitch zip tape to seam allowance.

Step 10 — Sleeves

Clip seam allowance on upper sleeve and undersleeve pieces diagonally toward top corner of marked lines for zip. Lay seam allowances to inside along long marked lines, trim to a width of 1 cm (3/8 in), and glue down (glue stick). Stitch back seams. Topstitch close to each side of seams. Lay seam allowance on short upper horizontal edge to inside and glue. Stitch zips under edges, from hem fold line, so that teeth are visible. Turn in bottom ends of zip tapes. Stitch front sleeve seams. Spread seam allowances apart and glue down (textile adhesive). Press sleeve hem allowances to inside, stitch 5 cm (2 ins) and 4.2 cm (1 good 1 5/8 ins)

from lower edge.

Step 11 — Sleeve Caps

Set in sleeves, easing sleeve caps. Sew shoulder pads in place.

Step 12 — Lining

Stitch side front lining pieces to front facings, leaving about 8 cm (3 1/4 ins) open at bottom. Stitch ease pleat in centre back lining piece, at top and bottom, each about 5 cm (2 ins) long, and baste in between. Press pleat to one side. Stitch back facing to centre back lining piece. Stitch centre back lining piece to peplum lining. Stitch back section seams, side seams and shoulder seams. Leave side seams open about 5 cm (2 ins) long at the bottom. Press hem allowance of lining to inside so that lining is 2 cm (3/4 in) shorter than jacket. Turn in hem allowance of lining in back (from side seam to side seam) and stitch. Stitch remainder of side seams. Sew sleeve linings and set in.

Step 13 — Collar and zip

Lay facing and lining right sides together with jacket. Stitch facing to hem edges, front edges, and neck edge. Zip and collar are caught in between. Trim seam allowances, trimming corners diagonally. Clip curves several times. Turn facing and lining to inside. Press hem allowance to inside. Lay facing forward and up. Stitch to seam allowances close to collar joining seam and back neck edge. Lay facing to the side and down again. Topstitch fronts 1 cm (3/8 in) from collar joining seam, beginning about 2 cm (3/4 in) above front end of collar and stitching as far up as possible.

Step 14 — Close lining

Turn in lower edges of front and lining toward each other and hold with a single straight pin. Reach between front and lining to pull out lower edges. Remove the pin but keep hold of the edges. Stitch lower edges of front and lining right sides together. Push edge back in. Glue hem allowance in place (textile adhesive). Stitch across remaining inside pleat seams over the finished hem. Lay extra length of lining down and press lightly. Sew remaining open edges of lining closed, in front. Glue inside edge of front facings to hem allowance (textile adhesive).

Step 15 — Lining sleeves

Pin a fold, about 1 cm (3/8 in) deep, in lining above sleeve hems. Turn in lining of sleeves and sew to hem allowance and zip tapes.

Step 16 — Hem edges

Topstitch close to hem edges, from front section seams, and close to front and upper edges, up to collar.

Step 17 — Buttonhole

Stitch closely around buttonhole marking on left front. Slash buttonhole open. Sew button to inside right front, to match buttonhole.

BurdaStyle

07/2010 Leather Jacket