

08/2010 Coat with belt

By: burda style magazine

<http://www.burdastyle.com/projects/082010-coat-with-belt>



Coat with belt burda style magazine patterns FAQ

Materials

stretch gabardine

Step 1 — Preparation

Trace the pattern pieces from the pattern sheet. Lengthen pieces 1 and 2 as indicated. Trace front facing from piece 1 as a separate pattern piece. Note different lines for right and left edges of back vent, but cut the right and left pieces the same size initially from the double layer of fabric.

The stitching lines on pieces 1 and 2 (armholes) are marked for size 44. Remark the stitching lines for sizes 46 — 52 at the same width.

Seam and hem allowances:

Seams and edges 1.5 cm (5/8 in), hem 6 cm (23/8 ins).

Step 2 — Cutting out



1 front 2x

â— front facing 2x

2 back 2x

3 upper sleeve 2x

4 undersleeve 2x

5 lower sleeve piece 2x

6 collar, on a fold 2x

7 collar band, on a fold 2x

8 back facing, on a fold 1x

9 pocket piece 4x

â— (twice just to lining line)

a) 2 welts cut on bias, 15.5 cm (6 1/4 ins) long, 6 cm (2 1/2 ins) wide, \hat{A} -finished width 3 cm (1 1/4 ins),

b) tie belt, a total of 180 â— 185 â— 190 â— 195 â— 200 cm (71 â— 7 23/4 â— 75 â— 7 63/4

â— 7 83/4 ins) long, 10 cm (4 ins) wide, finished width 5 cm (2 ins),

c) 2 belt carriers, a total of 18 cm (7 ins) long, 3 cm (1 1/4 ins) wide (incl. allowance).

Interfacing: See pattern layout. Also iron strips of interfacing, about 5 cm (2 ins) wide, to wrong side of fabric, over pocket markings. Iron Vilene Bias Tape onto edges of armholes.

Step 3 — Vent

Stitch centre back seam, leaving vent open at bottom. Press seam allowances onto left back. Press vent facings to inside, trim to 5.5 cm (2¼ ins) wide, and neaten. Press inside edges of facing to inside, 7 mm (¼ in) wide, and stitch in place. Pin vent closed. Topstitch top of vent diagonally as marked, catching underlap.

Step 4 — Bust darts

Stitch bust darts. Press darts down. Stitch side seams, shoulder seams and facing seams.

Step 5 — Welt pockets

Sew welt pockets on fronts: Fold welts lengthwise, with right side facing in, and stitch across ends. Turn welts right side out. Stitch welts right sides together with marked joining line on fronts so that welts point forward. Lay larger pocket pieces on fronts opposite welts and stitch 1 cm (3/8 in) from welt joining seams. These seams should be about 5 mm (3/16 in) shorter at each end than the welt joining seams. Slash between lines of stitching and clip diagonally toward ends of seams. Do not cut into pocket pieces. Pull pocket pieces to inside. Press welts over pocket openings. Work from inside to stitch smaller pocket pieces to seam allowances of welt joining seams. Fold small triangles of fabric at pocket opening ends to inside and sew to pocket pieces. Trim pocket pieces even and stitch together. Bind all edges of pocket pieces with bias tape. Edgestitch narrow edges of welts in place. Neaten edges of pocket pieces together.

Step 6 — Notched collar and front edges

Pin facings right sides together with coat. Pin lapel fold lines together. Build a little extra fullness into corners of lapels. Stitch facings along edges of lapels, from marking, and along front edges. Leave facings lying right sides together with coat for now. Stitch collar band pieces to collar pieces. Trim seam allowances and press open. Topstitch close to each side of seams. Stitch collar pieces together along outer edges, building a little extra fullness into top collar. Begin and end stitching exactly on seam line of joining edge. Turn collar right side out. Lay collar between coat and facing. Stitch undercollar to neck edge of coat, from each marking to corner. Clip seam allowances of fronts into corners. Stitch lengthwise edge of undercollar to neck edge of coat. Stitch top collar to facing, clipping seam allowances of facing into corners. Press seam allowances of collar joining seams open. Turn facing to inside. Pin collar joining seams together exactly. Lay back facing up and stitch seam allowances together, close to collar joining seam. Lay facing down again.

Step 7 — Trim

Trim allowance on inside edge of facing to 7 mm (¼ in) wide, neaten, press to inside, and stitch in place.

Step 8 — Facings and back vents

Unfold front facings and back vent facings at hem. Lay hem allowance to inside, turn in, and stitch 4 cm (15/8 ins) from fold edge. Lay facings to inside again and sew to hem allowance and to shoulder seams.

Step 9 — Back sleeve

Stitch back sleeve seams. Stitch upper sleeve and undersleeve pieces together. Press seam allowances down. Stitch front sleeve seams. Turn lower edges of sleeves to inside on fold line and press. Turn in inside edges and sew in place, at joining seams. Topstitch lower pieces 1.5 cm (5/8 in) from horizontal seams. Turn up lower edges of sleeves to abutting lines and press.

Step 10 — Sleeves

Set in sleeves, easing sleeve caps. Press seam allowances of sleeve inset seams onto front and back, above underarm curve. Topstitch fronts and back close to sleeve inset seams, as marked.

Step 11 — Belt carriers

Fold strip for belt carriers in half lengthwise, right side facing in. Stitch lengthwise edges together. Turn strip right side out. Topstitch edges. Cut strip into 2 pieces. Turn ends in for a finished length of 6 cm (23/8 ins). Stitch belt carriers over side seams. at waist level.

Step 12 — Tie belt

Fold tie belt lengthwise, right side facing in. Trim each end at an angle. Stitch edges together, leaving a section of seam open for turning. Turn belt right side out. Sew opening closed.

Step 13 — Buttonholes

Work buttonholes in right front.

BurdaStyle

08/2010 Coat with belt