

# 08/2010 Jacket with Standing Collar

By: burda style magazine

<http://www.burdastyle.com/projects/082010-jacket-with-standing-collars>

---

Jacket with Standing Collar burda style magazine patterns FAQ

## Materials

twill

---

### Step 1 — Preparation

Trace the pattern pieces from the pattern sheet. Follow lines and details for style 110. Note different lines on centre back piece for right and left edges of vent but first cut the right and left pieces the same size from the double layer of fabric.

The buttonhole on piece 1 is marked for size 36. Remark the buttonhole for the other sizes according to the size lines.

Seam and hem allowances:

Seams and edges 1.5 cm (5/8 in), back section seams and back sleeve seams 2 cm (3/4 in), hem and sleeve hems 4 cm (15/8 ins). Cut lining pieces with 1.5 cm (5/8 in) seam and hem allowance.

---

### Step 2 — Cutting out



Twill:

1 front 2x

2 centre back 2x

3 side back 2x

4 upper sleeve 2x

5 undersleeve 2x

6 standing collar, on a fold 2x

7 front facing 2x

8 back facing, on a fold 1x

9 flap 4x

10 upper left welt 1x

11 pocket piece

(upper left pocket) 1x

a) 2 binding strips (lower pockets), 21 1/2 — 21 1/2 — 21.5 — 21.5 — 22 cm (83/8 — 83/8 — 81/2 — 81/2 — 83/4 ins) long, 4 cm (15/8 ins) wide (incl. allowance),

b) 2 pocket pieces (lower pockets), 21 1/2 — 21 1/2 — 21.5 — 21.5 — 22 cm (83/8 — 83/8 — 81/2 — 81/2 — 83/4 ins) wide, 21 cm (83/8 ins) long (incl. allowance).

Lining: piece 1 to lining line; piece 2 minus neck facing, without vent allowance and at centre back with an ease pleat of about 2 cm (3/4 in); pieces 3, 4, 5 and 11; and also pocket piece (piece b).

Interfacing: See pattern layout. Iron strips of interfacing, about 3 cm (1 1/4 ins) wide, to wrong side of fabric, over pocket markings. Also interface hem allowances. Iron Vilene Bias Tape to neck and armhole edges.

### Step 3 — Front darts

On front pieces, cut along centre of each side dart to about 7 cm (2¾ ins) before point. Stitch side front darts. Trim dart allowances to 1 cm (3/8 in) wide and press open, pressing points of darts flat. Stitch darts in neck edge and press toward centre. Stitch side seams (seam number 4).

---

### Step 4 — Pockets with flaps

Stitch outer edges of each interfaced flap piece to flap piece with no interfacing, right sides together. Turn right side out. Trim seam allowances on joining edge to 1 cm (3/8 in) wide. Stitch flaps in place along joining lines, with flaps pointing up. Fold binding strips lengthwise and press, right side facing out. Baste doubled binding strip in place so that fold edge of binding lies 2.5 cm (1 in) below flap joining seam. Stitch binding in place, 1 cm (3/8 in) from fold edge. These seams should be about 5 mm (3/16 in) shorter at each end than the flap joining seams. Slash between lines of stitching and clip diagonally toward ends of seams. Do not cut into pocket pieces. Lay binding up and press. Press flaps over pocket openings. Stitch pocket lining pieces to seam allowances of binding joining seams and stitch fabric pocket pieces to seam allowances of flap joining seams. Lay pocket pieces down and press. Lay small triangles at pocket opening ends to inside. Stitch to pocket pieces and binding, from seam end to seam end. Trim pocket pieces even and stitch together.

---

### Step 5 — Welt pocket

Sew welt pocket at top of left front: Fold welt lengthwise, with right side facing in. Stitch across ends. Turn welt right side out. Stitch welt right sides together with front, along joining line, with welt pointing down. Lay fabric pocket piece on front, opposite welt, and stitch 1 cm (3/8 in) from welt joining seam. This seam should be about 5 mm (3/16 in) shorter at both ends than the welt joining seam. Slash between lines of stitching and clip diagonally toward ends of seam. Do not cut into pocket pieces. Pull pocket pieces to inside and press welt over pocket opening. Work from inside to stitch pocket lining to seam allowances of welt joining seam. Fold small triangles at pocket opening ends to inside and sew to pocket piece. Trim pocket pieces even and stitch together. Edgestitch narrow edges of welt in place. Sew narrow edges of welts in place by hand.

---

### Step 6 — Centre back seam and vent

Stitch centre back seam from upper edge to vent marking. Clip seam allowance of right centre back piece diagonally into corner at top of vent. Press centre seam open. Press edges of back vent under, noting different lines for right and left edges of vent. Trim facing on left edge of vent to 5 cm (2 ins) wide. Topstitch left centre back piece diagonally at top of vent, as marked, catching underlap.

---

### Step 7 — Back section seams

For the back section seams, first lay side back pieces right sides together with centre back unit and stitch seam allowances together, 1.2 cm (1/2 in) from marked seam line. Press seam allowances open. Then lay pieces wrong sides together so that the seam lies exactly along the fold. Now stitch section seams 1.2 cm (1/2 in) from fold edges. Press seam allowances to one side.

---

## Step 8 — Shoulders

Stitch shoulder seams (set back) on jacket and facing.

---

## Step 9 — Buttonholes

Work buttonholes in right front facing. Pin facing right sides together with jacket. Stitch facing in place along hem edge, front edges and edges of lapels, to marking. Leave facing lying right sides together with jacket for now.

---

## Step 10 — Standing collar

Lay collar pieces right sides facing. Stitch together on front and upper edges, beginning and ending stitching in front, exactly on seam line. Trim seam allowances. Turn collar right side out and press. Lay collar between jacket and facing. Stitch outer collar piece to neck edge of jacket and stitch inside collar piece to facing. Press seam allowances open. Turn facing to inside. Pin collar joining seams together. Lay facing in back up again and stitch seam allowances together, close to collar joining seam. Lay facing down.

---

## Step 11 — Vent facings

Unfold vent facings at hem. Press hem allowance to inside and sew in place by hand. Lay vent facings to inside again and sew in place over hem.

---

## Step 12 — Sleeve

Stitch back sleeve seams in the same manner as for back section seams. Stitch front sleeve seams in the normal manner. Press sleeve hem allowances to inside and sew in place by hand.

---

## Step 13 — Sleeve caps

Set in sleeves, easing sleeve caps.

---

## Step 14 — Jacket lining

Stitch allowances of centre seam of centre back lining together, 1 cm (3/8 in) above vent. For the ease pleat, stitch along centre back at top and bottom (above vent), each about 5 cm (2 ins) long, and baste in between. Press pleat and allowances on edges of vent onto left back piece. Stitch darts and seams of lining. Set in sleeve linings. Stitch lining to inside edges of facing, leaving about 8 cm (3 1/4 ins) open at the bottom. Lay lining inside jacket with wrong sides facing, pulling linings into sleeves. Turn in lining at back vent and pin to facing of right back piece. Trim other edge of lining to 1 cm (3/8 in) before pressed edge of underlap. Clip 1 cm (3/8 in) diagonally into top corner. Turn in edge of lining and pin to vent facing of left back. Pin lining at top of vent to underlap. Pin a fold, about 1 cm (3/8 in) deep, in lining, above jacket hem and sleeve hems. Turn in lining and sew to hem allowances by hand. Remove pins, lay extra length of lining down and press. In front, sew open edges of lining in place. Sew lining to back vent.

---

## Step 15 — Buttonholes

Work diagonal buttonhole in right front. Sew on buttons to match buttonholes. Stitch thread bars, about 1 cm (3/8 in) long, 5 cm (2 ins) from right front edge and centred between buttonholes on facing and also 5 cm (2 ins) above top buttonhole and below bottom buttonhole.

---

**BurdaStyle**

08/2010 Jacket with Standing Collar