

11/2010 Cropped velvet jacket

By: burda style magazine

<http://www.burdastyle.com/projects/112010-cropped-velvet-jacket>



Cropped velvet jacket burda style magazine patterns FAQ

Materials

velvet and duchesse as contrasting fabric

Step 1 — Preparation

Größen, Tailles, Sizes						2		3		4		
1	N		L		K		Oberweite Tour de poitrine Bust		Tailleweite Tour des taille Waist		Hüftweite Tour des hanches Hip	
	5'6" 168 cm		5'9" 176 cm		5'3" 160 cm		ins	cm	ins	cm	ins	cm
	US	Eur.	US	Eur.	US	Eur.						
	6	32	6	64	6	16	30	76	23	58	32 ½	82
	8	34	8	68	8	17	31 ½	80	24 ½	62	34	86
	10	36	10	72	10	18	33	84	26	66	35 ½	90
	12	38	12	76	12	19	34 ¾	88	27 ¾	70	37	94
	14	40	14	80	14	20	36 ¾	92	29 ¾	74	38 ¾	98
	16	42	16	84	16	21	37 ¾	96	30 ¾	78	40 ¾	102
	18	44	18	88	18	22	39 ½	100	32 ½	82	41 ¾	106
	20	46	20	92	20	23	41	104	34	86	43 ½	110
	22	48	22	96	22	24	43 ½	110	36 ¾	92	45 ¾	116
	24	50	24	100	24	25	45 ¾	116	38 ¾	98	48	122
	26	52	26	104	26	26	48	122	41	104	50 ½	128
	28	54	28	108	28	27	50 ½	128	43 ½	110	52 ¾	134
	30	56	30	112	30	28	52 ¾	134	45 ¾	116	55 ¾	140
	32	58	32	116	32	29	55 ¾	140	48	122	57 ¾	146
	34	60	34	120	34	30	57 ¾	146	50 ¾	128	60	152

Trace the pattern pieces from the pattern sheet. Follow lines and details for style 130.

The flap joining line on piece 1 is marked for size 34. For sizes 36 — 42, lay pattern pieces 1 and 2 together (note markings). Lengthen flap joining line of side piece toward the front and mark front end 4 cm (15/8 ins) from section seam.

Seam and hem allowances:

Seams and edges 1.5 cm (5/8 in), back vent edges 4 cm (15/8 ins), hem and sleeve hems 4 cm (15/8 ins). Cut lining pieces with 1.5 cm (5/8 in) seam and hem allowances.

Step 2 — Cutting out

Velvet:

1— centre front 2x

2— side front 2x

3— centre back 2x

4— side back 2x

5— upper sleeve 2x

6— under sleeve 2x

7— under collar, on a fold 1x

8— outer collar stand, on a fold 1x

a) 2 binding strips, 16 — 17 — 17 — 18 — 18 cm (63/8 — 63/4 — 63/4 — 7 — 7 ins) long, 4 cm (15/8 ins) wide (incl. allowances),

b) 2 pocket pieces, 16 — 17 — 17 — 18 — 18 cm (63/8 — 63/4 — 63/4 — 7 — 7 ins) wide, 12 cm (43/4 ins) long (incl. allowances).

Duchesse (contrasting fabric):

7— top collar, on a fold 1x

8— inside collar stand, on a fold 1x

9— front facing 2x

10— back facing, on a fold 1x

11— flap 4x

Lining: piece 1 to lining line; piece 3 minus neck facing and with an ease pleat of about 2 cm (3/4 in) at

centre back; pieces 2, 4, 5 and 6; and piece b.

Interfacing: See pattern layout. Also interface hem allowances. Iron interfacing to outer flap pieces.

Step 3 — Front darts

Stitch front darts and press toward centre. Stitch centre back seam, ending stitching about 10 cm (4 ins) above slit mark. Stitch front and back section seams, stitching front section seams only to 5 cm (2 ins) before marked hem line. Stitch side seams, shoulder seams and seams of facing. Press seam allowances open.

Step 4 — Pockets with flaps

Stitch each interfaced flap piece to flap piece with no interfacing, along outer edges, right sides together. Turn right side out. Trim seam allowances of joining edge to 1 cm (3/8 in) wide. Stitch flaps in place, along joining lines, with flaps pointing up. Fold binding strips lengthwise and press, right side facing out. Baste folded binding strips in place so that fold edge of binding lies 2.5 cm (1 in) below flap joining seam. Stitch binding in place, 1 cm (3/8 in) from fold edge. These seams should be about 5 mm (3/16 in) shorter than the flap joining seams at each end. Slash between lines of stitching and clip diagonally toward each last stitch. Do not cut into pocket pieces. Lay binding up and press. Press flaps over pocket openings. Stitch pocket lining pieces to seam allowances of binding joining seams and stitch pocket pieces of main fabric to seam allowances of flap joining seams. Lay pocket pieces down and press. Lay small triangles on pocket opening ends to inside and stitch to pocket pieces and binding, from seam end to seam end. Trim pocket pieces even and stitch together.

Step 5 — Notched collar

Stitch collar stand pieces to collar pieces. Trim seam allowances and press open. Topstitch close to each side of seams. Stitch collar pieces together along outer edges, building a little extra fullness into top collar and beginning and ending stitching exactly on seam line of joining edge. Turn collar right side out. Pin facings right sides together with jacket. Pin lapel fold lines together. Pin upper edges together at marking (seam number 5). Build a little extra fullness into corners of lapels. Stitch along hem edges, from front section seams, along front edges and edges of lapels, to marking. Clip seam allowances of fronts and facing at marking, close to end of seam. Leave facings lying right sides together with jacket for now. Lay collar between jacket and facing. Stitch undercollar to neck edge of jacket, from each marking to corner. Clip seam allowance of fronts into corners. Stitch lengthwise edge of undercollar to neck edge of jacket. Stitch top collar piece to facing, clipping seam allowance of facing into corners. Press seam allowances of collar joining seams open. Turn facing to inside. Pin collar joining seams together exactly. Lay back facing up and stitch seam allowances together, close to collar joining seam. Lay facing down again.

Step 6 — Ti

To keep the pointed lapels in place, sew them to the underside of the collar with a few stitches, by hand.

Step 7 — facings

Lay facings at front section seams down again. Stitch remainder of section seams, up to inside edges of facing

Step 8 — Mitred corners

On back hem corners, sew mitred corners: Lay hem and slit allowances to outside and stitch diagonally. Trim allowances of mitring seams to 5 mm (3/16 in) wide and press open. Turn hem and slit allowances to inside and press.

Step 9 — Back

Stitch remainder of centre back seam, up to slit mark. Sew hem allowance in place by hand.

Step 10 — Sleeve

Stitch sleeve seams. Press sleeve hem allowances to inside and sew in place by hand.

Step 11 — Sleeve caps

Set in sleeves, easing sleeve caps. Sew shoulder pads in place.

Step 12 — Sew lining

Stitch allowances of centre seam on centre back lining piece together, 1 cm (3/8 in) from edge, above vent. For the ease pleat, stitch along centre back, about 5 cm (2 ins) long, at top and bottom (above vent) and baste in between. Press pleat to one side. Stitch seams of lining. Set in sleeve linings.

Step 13 — Line jacket

Stitch lining to inside edge of facing, leaving about 8 cm (3 1/4 ins) open at bottom. Place lining inside jacket with wrong sides facing, pulling linings into sleeves. Pin a fold in lining, about 1 cm (3/8 in) deep, above jacket hem and sleeve hems. Turn in lining and sew to hem allowances by hand. Remove pins, lay extra length of lining down, and press. Sew remaining front edges of lining in place. Pin lining to top of back vent. Trim lining to 2 cm (3/4 in) before inside edges of vent allowances and across top of vent and clip about 1 cm (3/8 in) diagonally into top corners. Turn in lining and sew to vent allowances.

Step 14 — Buttonhole

Work one buttonhole each in right and left fronts — left buttonhole for inside button.

BurdaStyle

11/2010 Cropped velvet jacket