

# 11/2010 Jacket with contrasting collar

By: burda style magazine

<http://www.burdastyle.com/projects/112010-jacket-with-contrasting>

---



Jacket with contrasting collar burda style magazine patterns FAQ

## Materials

gabardine and wide duchesse as contrasting fabric

---

## Step 1 — Preparation

Größen, Tailles, Sizes						2		3		4		
1	N		L		K		Oberweite Tour de poitrine Bust		Tailleweite Tour des taille Waist		Hüftweite Tour des hanches Hip	
	5'6" 168 cm		5'9" 176 cm		5'3" 160 cm		ins	cm	ins	cm	ins	cm
	US	Eur.	US	Eur.	US	Eur.						
	6	32	6	64	6	16	30	76	23	58	32 ½	82
	8	34	8	68	8	17	31 ½	80	24 ½	62	34	86
	10	36	10	72	10	18	33	84	26	66	35 ½	90
	12	38	12	76	12	19	34 ½	88	27 ½	70	37	94
	14	40	14	80	14	20	36 ½	92	29 ½	74	38 ½	98
	16	42	16	84	16	21	37 ½	96	30 ½	78	40 ½	102
	18	44	18	88	18	22	39 ½	100	32 ½	82	41 ½	106
	20	46	20	92	20	23	41	104	34	86	43 ½	110
	22	48	22	96	22	24	43 ½	110	36 ½	92	45 ½	116
	24	50	24	100	24	25	45 ½	116	38 ½	98	48	122
	26	52	26	104	26	26	48	122	41	104	50 ½	128
	28	54	28	108	28	27	50 ½	128	43 ½	110	52 ½	134
	30	56	30	112	30	28	52 ½	134	45 ½	116	55 ½	140
	32	58	32	116	32	29	55 ½	140	48	122	57 ½	146
	34	60	34	120	34	30	57 ½	146	50 ½	128	60	152

Trace the pattern pieces from the pattern sheet.

The pocket lines on piece 21 are marked for size 36. For sizes 38 — 44, remark the pocket lines according to the size lines — for each size, the pocket begins 2 cm (3/4 in) before the dart.

Lining: Glue paper pattern pieces 26 and 27 together (seam number 4).

Seam and hem allowances:

Seams and edges 1.5 cm (5/8 in); no allowances on horizontal edges of front (marked with scissors symbol) but 1.5 cm (5/8 in) allowance at dart; hem and sleeve hems 4 cm (15/8 ins). Cut lining pieces with 1.5 cm (5/8 in) seam and hem allowances.

---

## Step 2 — Cutting out



Gabardine:

21front 2x

22front armhole band 2x

23back 2x

24back armhole band 2x

25back neck band, on a fold 1x

26side piece 2x

27side armhole band 2x

28upper sleeve 2x

29under sleeve 2x

31back facing, on a fold 1x

32under collar, on a fold 1x

33collar stand (undercollar),

— on a fold 1x

a) 4 binding strips (pockets), 17 cm (63/4 ins) long, 3 cm (11/4 ins) wide (incl. allowances),

b) 2 pocket pieces, 17 cm (63/4 ins) wide, 16 cm (63/8 ins) long (incl. allowances).

Duchesse:

30front facing with top collar 2x

33collar stand (top collar),

— on a fold 1x

c) 4 flap pieces, 14 cm (51/2 ins) long, 5.5 cm (21/4 ins) wide.

Lining:

34front lining piece 2x

35back lining piece 2x

piece 26 and 27 placed together; pieces 28 and 29; and pocket pieces (piece b).  
Interfacing: See pattern layout. Also interface hem allowances.

---

### **Step 3 — Back seam**

Stitch centre back seam. Press seam allowances open.

---

### **Step 4 — Arm and neck**

Stitch armhole bands to fronts, back and side pieces. Stitch back neck band to back. Clip seam allowances along curves several times. Press seam allowances open.

---

### **Step 5 — Bust Darts**

Stitch bust darts. Cut close to end of seam at lower horizontal edge of fronts. Press darts open, pressing points of darts flat. Lay horizontal edges of fronts together and baste together with herringbone stitches by hand. Stitch side pieces to fronts.

---

### **Step 6 — Flaps**

For each flap, stitch 2 flap pieces together along side and lower edges, slightly rounding off corners. Trim seam allowances. Turn right side out and press

---

### **Step 7 — Bound pockets with flaps**

Mark an abutting line for each binding strip, 7 mm (1/4 in) from each joining line (= finished width of binding). Hand baste along these lines to make them visible on right side of fabric. Fold binding strips lengthwise and press, wrong side facing in. Lay folded binding strips on front pieces and side pieces and pin so that fold edges of binding meet abutting lines. Stitch binding in place along joining lines, 7 mm (1/4 in) from fold edges. Slash between lines of stitching and clip diagonally toward each last stitch, but do not cut into binding. Press binding into pocket opening. Fold small triangles at pocket opening ends to inside and stitch to binding, from seam end to seam end. Slip joining edges of flaps through pocket openings to inside and stitch to seam allowances, close to binding joining seam. Stitch pocket lining pieces to seam allowances of lower binding and stitch pocket pieces of main fabric to seam allowances of flaps and upper binding. Trim pocket pieces even and stitch together.

---

### **Step 8 — Shoulder seams**

Stitch side pieces to back. Stitch shoulder seams.

---

### **Step 9 — Collar**

Stitch respective collar stand piece to undercollar. Trim seam allowances and press open. Topstitch close to each side of seam. Stitch undercollar with collar stand to neck edge of jacket, clipping seam allowances of fronts into corners. Press seam allowances open. Stitch centre back seam on integrated top collar pieces of front facings. Stitch back facing to inside edge of duchesse collar stand piece (seam number 8). Stitch back facing and collar stand to narrow edges of front facings and inside edge of top collar, clip seam allowances into corners. Stitch front facings right sides together with fronts, then stitch edges of collar together. Turn

facing to inside and turn collar right side out. Press edges. Pin collar joining seams together exactly. Lay back facing up and stitch seam allowances together, close to collar joining seam. Lay facing down.

---

## **Step 10 — Hem allowance**

Press hem allowance to inside and sew in place by hand.

---

## **Step 11 — Sleeve seams**

Stitch sleeve seams. Press sleeve hem allowances to inside and sew in place by hand.

---

## **Step 12 — Sleeve caps**

Set in sleeves, easing sleeve caps. Sew shoulder pads in place.

---

## **Step 13 — Sew lining**

Stitch centre seam of back lining. Stitch ease pleat as marked on pattern. Press pleat to one side. Stitch darts and remaining seams of lining. Set in sleeve linings.

---

## **Step 14 — Line jacket**

Stitch lining to inside edge of facing, leaving about 8 cm (3 1/4 ins) open at bottom. Place lining inside jacket with wrong sides facing, pulling linings into sleeves. Pin a fold in lining, about 1 cm (3/8 in) deep, above jacket hem and sleeve hems. Turn in lining and sew to hem allowances by hand. Remove pins, lay extra length of lining down, and press. Sew remaining front edges of lining in place.

---

## **Step 15 — Buttonholes**

Work buttonholes in front.

---

**BurdaStyle**

11/2010 Jacket with contrasting collar