

02/2011 Safari Jacket

By: burda style magazine

<http://www.burdastyle.com/projects/022011-safari-jacket>



Safari Jacket burda style magazine patterns FAQ

Materials

fine gabardine with crosswise stretch

Step 1 — Preparation

Größen, Tailles, Sizes						2		3		4		
1	N		L		K		Oberweite Tour de poitrine Bust		Tailleweite Tour des taille Waist		Hüftweite Tour des hanches Hip	
	5'6" 168 cm		5'9" 176 cm		5'3" 160 cm		ins	cm	ins	cm	ins	cm
	US	Eur.	US	Eur.	US	Eur.						
	6	32	6	64	6	16	30	76	23	58	32 ½	82
	8	34	8	68	8	17	31 ½	80	24 ½	62	34	86
	10	36	10	72	10	18	33	84	26	66	35 ½	90
	12	38	12	76	12	19	34 ¾	88	27 ¾	70	37	94
	14	40	14	80	14	20	36 ¾	92	29 ¾	74	38 ¾	98
	16	42	16	84	16	21	37 ¾	96	30 ¾	78	40 ¾	102
	18	44	18	88	18	22	39 ½	100	32 ½	82	41 ¾	106
	20	46	20	92	20	23	41	104	34	86	43 ½	110
	22	48	22	96	22	24	43 ½	110	36 ¾	92	45 ¾	116
	24	50	24	100	24	25	45 ¾	116	38 ¾	98	48	122
	26	52	26	104	26	26	48	122	41	104	50 ¾	128
	28	54	28	108	28	27	50 ½	128	43 ½	110	52 ¾	134
	30	56	30	112	30	28	52 ¾	134	45 ¾	116	55 ¾	140
	32	58	32	116	32	29	55 ¾	140	48	122	57 ¾	146
	34	60	34	120	34	30	57 ¾	146	50 ¾	128	60	152

Trace the pattern pieces from the pattern sheet. Cut piece 1 apart on the marked seam line = front and front band with self-facing. Cut piece 10 apart on the marked seam line.

The snap fasteners marked on piece 1 are for size 18. For the other sizes, mark the top snap the same distance from neck edge as for size 18. The bottom snap is the same for all sizes. Mark the other snaps evenly in between.

Seam and hem allowances:

Seams and edges 1.5 cm (5/8 in), hem 4 cm (15/8 ins), lining 1.5 cm (5/8 in).

Step 2 — Cutting out



Fine gabardine:

1 front 2x

1 front band with self-facing 2x

2 centre back 2x

3 side back 2x

4 upper sleeve 2x

5 under sleeve 2x

6 collar, on a fold 2x

7 collar stand, on a fold 2x

8 back facing, on a fold 1x

9 flap (upper pocket) 4x

10 upper pocket, cut apart, each 2x

11 flap (lower pocket) 4x

12 lower pocket 2x

a) 2 cuffs, 26 — 27 — 28 — 29 — 30 cm (10 1/4 — 10 5/8 — 11 — 11 1/2 — 12 ins) long, 12 cm (4 3/4 ins) wide, finished width 6 cm (2 3/8 ins),

b) 4 tab pieces (shoulder), 10 — 10 — 11 — 11 — 11 cm (4 — 4 — 4 3/8 — 4 3/8 — 4 3/8 ins) long, 4 cm (1 5/8 ins) wide.

Lining: piece 1 to lining line; piece 2 minus neck facing and without slit allowances but with an ease pleat, about 2 cm (3/4 in) wide, at centre back; pieces 3, 4, and 5.

Interfacing: See pattern layout. Also interface hem allowances. Iron interfacing to undercollar piece.

Step 3 — Darts

Stitch front darts. Press darts open, pressing points of darts flat. Stitch side seams.

Step 4 — Upper pockets

For each pocket, stitch pocket pieces together along centre, from upper to lower edges. Topstitch front pocket pieces close to seam. Lay self-facings on upper pocket edges to inside and stitch 2 cm (3/4 in) from fold. Press allowances on side and lower edges to inside. Edgestitch pockets in place on fronts, at abutting lines.

Step 5 — Lower pockets

Stitch darts in pockets. Press darts down. Topstitch close to dart seams. Lay self-facings on upper pocket edges to inside and stitch 2 cm (3/4 in) from fold. Press allowances on side and lower edges to inside. Edgestitch pockets in place on jacket, at abutting lines.

Step 6 — Upper and lower flaps: Upper and lower flaps

Stitch each interfaced flap piece to a flap piece with no interfacing, right sides together, leaving joining edge open. Turn right side out. Topstitch close to edges and again 7 mm (1/4 in) from edges. Trim allowances at joining edges to 7 mm (1/4 in) wide. Stitch upper flaps in place, 1.5 cm (5/8 in) above upper pockets. Stitch lower flaps in place, 2.5 cm (1 in) above lower pockets. Press flaps down and stitch again 7 mm (1/4 in) from joining seams.

Step 7 — Back seam

Stitch centre back seam. Press seam allowances open. Stitch back section seams, leaving bottom vents open. Press seam allowances and allowances at edges of vents onto centre back. Stitch shoulder seams on jacket and on facing.

Step 8 — Facings

Stitch front bands to fronts. Press seam allowances onto bands. Lay self-facings to outside and stitch to upper edge, from front edge (fold) to band joining seam. Leave facings lying right sides together with jacket for now.

Step 9 — Collar

Stitch collar stand pieces to collar pieces. Trim seam allowances and press open. Topstitch close to each side of seams. Stitch collar pieces right sides together along outer edges, from seam number 4. Begin and end stitching at narrow edges exactly on seam line of joining edge. Trim seam allowances. Turn collar right side out and press. Lay collar between jacket and facing. Stitch undercollar to neck edge of jacket and stitch top collar to facing. Press seam allowances open. Turn facing to inside. Pin collar joining seams together exactly. Lay back facing up and stitch seam allowances together, close to collar joining seam. Lay facing down again. Topstitch close to edges of collar and again 7 mm (1/4 in) from edges.

Step 10 — Hem

Unfold facings at hem. Press hem allowance to inside but do not yet sew. Lay facings to inside again. Press front edges.

Step 11 — Mitred corners

Sew mitred corners at corners of hem on centre back piece. Lay allowances at hem and vent edges to outside and stitch a diagonal seam. Trim allowances of mitring seams to a width of 5 mm (3/16 in) and press open. Turn allowances at hem and vent edges to inside and press. On side back pieces, lay hem allowance of vent underlap to outside and stitch to vertical edge of underlap. Turn hem allowance to inside and press allowance on underlap edge to inside. Sew hem allowance in place by hand. Sew front facings to hem allowance. Topstitch centre back vertically as marked, close to vent edges. Angle topstitching at top of each vent, catching underlaps.

Step 12 — Shoulder tabs

Lay each interfaced tab piece on a tab piece with no interfacing, right sides together. Trim one end of each tab to a point. Stitch along lengthwise edges and pointed end of tabs. Turn right side out. Topstitch tabs. Lay tabs on shoulder seams and baste to armhole edges. Fasten shoulder tabs to shoulder seams with one snap each, not catching facing.

Step 13 — Sleeve seams

Stitch back sleeve seams above vent mark. Clip seam allowance of under sleeves at ends of vents. Topstitch upper sleeves close to seams. Stitch front sleeve seams.

Step 14 — Sleeve caps

Set in sleeves, easing sleeve caps.

Step 15 — Pleat

Stitch allowances of centre seam on back lining pieces together 1 cm (3/8 in) from edge. For the ease pleat, stitch along centre back at top and bottom, each about 5 cm (2 ins) long, and baste in between. Press pleat to one side. Stitch darts and seams of lining. Set in sleeve linings, eased to fit.

Step 16 — Lining

Stitch lining to inside edge of facing, leaving about 8 cm (3 1/4 ins) open at bottom. Lay lining inside jacket, with wrong sides facing, pulling linings into sleeves. Turn in lining at back vents and pin to edges of side back pieces. Trim other edges of lining each to 1 cm (3/8 in) before pressed edge of underlap. Clip 1 cm (3/8 in) diagonally into top corners. Turn in edges of lining and pin to vent facings of centre back. Turn in lining and pin to underlap, at top of vents. Pin a fold, about 1 cm (3/8 in) deep, in lining, above hem of jacket. Turn in lining and sew to hem allowances by hand. Lay extra length of lining down and press. Sew open edges of lining in place, on fronts. Sew lining in place at back vents.

Step 17 — Lining

Turn in lining and baste to sleeve vents. Topstitch close to edges of vents. Topstitch 7 mm (1/4 in) from front edges of vents. Stitch 1 cm (3/8 in) across top of each vent. Baste lining to lower edges of sleeves without turning in.

Step 18 — Cuffs

Stitch cuffs to lower edges of sleeves. Press allowances of joining seam and of other long edges of cuffs onto cuffs. Fold cuffs lengthwise, right side facing in, and stitch across ends. Turn right side out. Baste inside edges in place. Topstitch cuffs close to joining seams. Topstitch close to remaining edges of cuffs and again 7 mm (1/4 in) from these edges.

Step 19 — Bands and cuffs

Topstitch front bands close to joining seam and close to upper and front edges. Attach snap fasteners to front band, with top halves of snaps on the right and bottom halves on the left. Fasten cuffs with 2 snaps each.

BurdaStyle

02/2011 Safari Jacket