

3/2011 Peplum Jacket

By: burda style magazine

<http://www.burdastyle.com/projects/32011-peplum-jacket>



Peplum Jacket burda style magazine patterns FAQ

Materials

Jacquard fabric

Step 1 — Preparation

Trace the pattern pieces from the pattern sheet. Trace the facing from piece 1 as a separate pattern piece.

Seam and hem allowances:

Seams and edges 1.5 cm (5/8 in), sleeve hems 4 cm (15/8 ins), lining 1.5 cm (5/8 in).

Step 2 — Cutting Out



Jacquard:

1 front 2x

2 front facing 2x

3 back 2x

4 upper sleeve 2x

5 under sleeve 2x

6 collar, on a fold 2x

7 collar stand, on a fold 2x

8 back facing, on a fold 1x

9 front peplum 4x

10 back peplum, on a fold 2x

Lining: piece 1 minus width of facing; piece 2 minus neck facing and with an ease pleat, approx. 2 cm (3/4 in) wide, at centre back; and also pieces 3 and 4.

Interfacing: See pattern layout. Also interface sleeve hem allowances.

Step 3 — Darts

Stitch darts. Press vertical darts toward centre front/centre back. Press bust darts down.

Step 4 — Stitch centre back seam, side seams, and shoulder seams

Stitch centre back seam, side seams, and shoulder seams. Stitch shoulder seams of facing. Press seam allowances open.

Step 5 — Notched collar

Pin facing right sides together with jacket. Pin lapel fold lines together. Build a little extra fullness into corners of lapels. Stitch facing to jacket, along lapel edges, from marking, and along front edges. Leave facing lying right sides together with jacket for the time being. Stitch collar stand pieces to collar pieces. Trim seam allowances and press open. Topstitch close to each side of seams. Stitch collar pieces together on outer edges, building a little extra fullness into top collar and beginning and ending stitching on narrow edges, exactly at seam line of joining edge. Turn collar right side out. Lay collar between jacket and facing. Stitch under collar to neck edge of jacket, from each seam mark to corner. Clip seam allowances of fronts into corners. Stitch long edge of undercollar to neck edge of jacket. Stitch top collar to facing, clipping seam allowances of facing into corners. Press seam allowances of collar joining seams open. Turn facing to inside. Pin collar joining seams together exactly. Lay back facing up and stitch seam allowances together, close to collar joining seam. Lay facing down again.

Step 6 — Stitch sleeve seams

Stitch sleeve seams. Press sleeve hem allowances to inside and sew in place by hand.

Step 7 — Set in sleeves, easing sleeve caps

Set in sleeves, easing sleeve caps. Sew shoulder pads in place.

Step 8 — Stitch side seams of peplum

Stitch side seams of peplum. Lay peplum units right sides together and stitch together along front and lower edges. Trim seam allowances. Turn peplum units right side out and press edges. Baste upper edges together. Fold pleats in direction of arrows and baste. Unfold facings at bottom end of front edges. Stitch peplum right sides together with lower edge of front and back pieces. Leave peplum lying on jacket for the time being.

Step 9 — Ease pleat

On back lining, stitch allowances of centre seam together, 1 cm (3/8 in) from edge. For ease pleat, stitch along centre back, about 5 cm (2 ins) long, at both top and bottom, and baste in between. Press pleat to one side. Stitch darts and seams of lining. Set in sleeve linings.

Step 10 — Stitch lining right sides together with inside edge of facing

Turn facing out onto jacket again. Stitch lining right sides together with inside edge of facing. Stitch lower edges of facing and lining right sides together with lower front and back edges, as continuous seam, catching peplum in seam and leaving an opening, approx. 25 cm (10 ins) long at centre back, for turning. Turn jacket right side out. Pull sleeve linings into jacket sleeves. Sew remaining open edge of lining in place by hand. Pin a fold, about 1 cm (3/8 in) deep, in lining, above sleeve hems. Turn in edges of sleeve linings and sew to hem allowances. Lay extra length of lining down and press.

Step 11 — Snaps

Cover snap fasteners with outer fabric. Sew top halves of snaps to inner side of right front, taking even stitches and exiting needle on right fabric side. Sew bottom halves of snaps to left front, to match.

BurdaStyle

3/2011 Peplum Jacket