

09/2011 Jacket with standing collar Plus Size

By: burda style magazine

<http://www.burdastyle.com/projects/092011-jacket-with-standing-c>



Jacket with standing collar plus size sewing pattern. burda style magazine patterns FAQ

Materials

Fulled loden cloth

Step 1 — Preparation



Paper cut for ANSI A (German DIN A4) prints:

This pattern is printed on 8.5 × 11 sheets of plain paper. Do not scale or center pages before printing. Wait until all sheets are printed out before beginning to tape them together. **Do not cut out pattern pieces yet**— Arrange the sheets on a large, hard, flat surface so that they fit together, matching up like numbers and letters (i.e. 6A to 6A). To tape pattern together, fold under the margin of one piece (6A) and tape right against the line of it's matching number/letter (6A).

burda style magazine pattern do not have seam allowance included.

Seam and hem allowances to be added: Seams and edges 1.5 cm (5/8 in).

see example here: <http://www.burdastyle.com/projects/072011-jumpsuit/instructions/1>

Step 2 — Cutting out



Fulled loden:

21centre front 2x

22side front 2x

23upper centre back 2x

24lower centre back 2x

26side back 2x

27upper sleeve 2x

28under sleeve 2x

Velvet:

21front facing 2x

25pleat underlay 1x

27upper sleeve facing 2x

28under sleeve facing 2x

29standing collar, on a fold 2x

30back facing, on a fold 1x

a) fastening underlap, 20 $\hat{=}$ 21 $\hat{=}$ 21 $\hat{=}$ 22 $\hat{=}$ 23 cm (8 $\hat{=}$ 83/8 $\hat{=}$ 83/8 $\hat{=}$ 83/4 $\hat{=}$ 91/8 ins) long, 26 cm (10 1/2 ins) wide, finished width 13 cm (5 1/4 ins).

Lining: pieces 21, 27, and 28 minus width of facing; pieces 23 and 24 placed together, minus neck facing and with an ease $\hat{=}$ pleat of approx. 2 cm (3/4 in) at centre back; also pieces 22 and 26.

Interfacing: See pattern layout. Iron interfacing to wrong side of half the fastening underlap.

Step 3 — Back

Lay upper centre back pieces each wrong sides together. Stitch centre back seam. Trim seam allowances to 7 mm (1/4 in) wide and press open — seam allowances lie on the right side of the garment.

Step 4 — Mitre the corners

Mitre the corners of the hem on lower centre back: Turn the self-facings at centre back and the hem allowances to outside and stitch diagonally to mitre the corners. Trim the allowances of mitring seams to 5 mm (3/16 in) wide and press open. Turn facings and hem allowances to inside.

Step 5 — Shoulders

Lay lower centre back pieces together at back edges and baste with herringbone stitch. Stitch upper centre back to lower centre back as instructed for centre back seam. Stitch front and back section seams and side seams, wrong sides facing. Stitch shoulder seams in the — normal — manner. Stitch shoulder seams of facing.

Step 6 — Standing collar and front edges

Stitch outer collar piece to neck edge and stitch inside collar piece to facing. Press seams open. Pin facing right sides together with jacket, pinning collar pieces together. Stitch along front edges and edges of collar. Trim seam allowances. Turn collar right side out and turn facing to inside. Press seamed edges. Pin collar joining seams together exactly. Turn back facing up again and stitch allowances together, close to collar joining seam. Turn facing down again.

Step 7 — Facings

Unfold facings at hem. Press hem allowance to inside and sew in place by hand.

Step 8 — Pleat

Hem pleat underlay. Work from inside to lay pleat underlay on lower centre back and pin in place. Work from right side to stitch along vertical seams and horizontal seam.

Step 9 — Sleeves

Stitch the front sleeve seams, wrong sides facing. On sleeve facings, stitch front seams in — normal — manner. Pin the sleeve facings right sides together with the lower edges of the sleeves. Beginning at slit mark, stitch along the edges of the sleeve vents and the hem edges. Turn upper edge of facings back at ends of seams and pin. Clip seam allowances of sleeves at slit marks. Stitch back sleeve seams, wrong sides facing. On sleeve facings, stitch back seam, right sides facing. Turn facings to inside. Press edges of hem and vents. Sew inside edges of facings in place by hand.

Step 10 — Sleeve caps

Set in sleeves, easing sleeve caps. Sew shoulder pads in place.

Step 11 — Buttonholes

Work buttonholes in both fronts. Do not cut open buttonholes on left front.

Step 12 — Underlap

Fold the fastening underlap piece lengthwise, right side facing in. Stitch the edges together, on the long edge leaving a section of seam open, for turning. Turn underlap right side out and press. Sew seam opening closed. Lay underlap on left front facing to meet abutting line. Edgestitch narrow top and bottom ends and long edge to facing.

Step 13 — Sew lining

On centre back lining pieces, stitch the allowances of the centre seam together, 1 cm (3/8 in) from edge. For the ease pleat, stitch along the centre back, approx. 5 cm (2 ins) long, from upper edge down and from lower edge up, and baste the pleat in between. Press the pleat to one side. Stitch the seams of the lining. Set in sleeve linings.

Step 14 — Sew in lining

Sew in lining: Stitch lining to inside edge of facing, leaving approx. approx. 6 cm (23/8 ins) open at the bottom. Lay the lining inside the jacket, with wrong sides facing, pulling linings into sleeves. Above hem of jacket, pin a fold, approx. 1 cm (3/8 in) deep, in lining. Turn lining edge under and sew to the hem allowances by hand. Lay extra length down and press. Sew the remaining front edges of the lining to the facings. Turn in the sleeve linings and sew to the inside edges of the facings.

Step 15 — Buttons

Lay front edges together. Sew buttons to underlap, to match button holes. Sew buttons to left front, at beginning of buttonholes. At each sleeve vent, sew one button to upper end of vent.

BurdaStyle

09/2011 Jacket with standing collar Plus Size