

10/2011 Plus size zip up jacket

By: burda style magazine

<http://www.burdastyle.com/projects/102011-plus-size-zip-up-jacket>



Jacket with front zipper burda style magazine patterns FAQ

Materials

Brushed wool

Step 1 — Preparation



Paper cut for ANSI A (German DIN A4) prints:

This pattern is printed on 8.5 × 11 sheets of plain paper. Do not scale or center pages before printing. Wait until all sheets are printed out before beginning to tape them together. **Do not cut out pattern pieces yet**— Arrange the sheets on a large, hard, flat surface so that they fit together, matching up like numbers and letters (i.e. 6A to 6A). To tape pattern together, fold under the margin of one piece (6A) and tape right against the line of it's matching number/letter (6A).

burda style magazine pattern do not have seam allowance included.

Seam and hem allowances to be added: Seams and edges 1.5 cm (5/8 in).

Step 2 — Cutting out



Brushed wool:

1 front with integrated sleeve 2x

2 pocket piece 2x

3 back with integrated sleeve 2x

4 side piece 2x

5 under sleeve piece 2x

6 front facing 2x

7 back facing, on a fold 1x

a) 2 shoulder tabs, 34 — 35 — 36 — 37 — 38 cm (13 1/2 — 13 3/4 — 14 1/4 — 14 1/2 — 15 ins) long, 6 cm (2 1/2 ins) wide, finished width 3 cm (1 1/4 ins).

Lining: piece 1 to lining line; piece 2 minus width of facing and with an ease pleat of approx. 2 cm (3/4 in) at centre back; pieces 3 and 4; and also the pocket piece.

Interfacing: See pattern layout. Also interface hem allowances.

Step 3 — Pleat

Work from inside to stitch the pleat in each front, exactly from the marked seam line at upper edge to the arrow. Lay the pleat in direction of arrow and press pleat seam. Trim pleat allowances to 1.5 cm (5/8 in) wide, beginning at upper edge. At upper end of pleat seam, spread seam allowances open and iron, tapering the allowances as you go.

Step 4 — Darts

Stitch centre back seam and back darts. Press centre seam open and press darts toward centre back.

Step 5 — Fronts

Lay the fronts wrong sides together with the back. Pin together along shoulder edges and along upper sleeve seam edges. Stitch the shoulder seams and upper sleeve seams as continuous seam. Press the seam allowances open. Edgestitch edges of seam allowances in place.

Step 6 — Sides

Stitch side pieces to fronts, from marking (seam number 2) to corner (seam number 3). Stitch side pieces to back, from marking (seam number 2) to corner (seam number 4). At bottom end of each side piece, fold seam allowance up and pin. Stitch the side seams, but do not stitch across pocket openings.

Step 7 — Inseam pockets

Pin pocket pieces right sides together with the seam allowances of the pocket opening edges — pocket lining pieces in front and pocket pieces of outer fabric in back. Stitch pocket pieces of outer fabric in place, close to the side seam and along the seam line at pocket opening edges. Stitch the pocket lining pieces to the seam allowances, 7 mm (1/4 in) from the seam line. Press the pocket pieces forward, trim even, and stitch together. Baste lower edges of pocket pieces in place.

Step 8 — Seam allowances

Clip the seam allowance of the fronts into the top corner (seam number 3), diagonally toward end of seam. Press the seam allowances open. Stitch the under sleeve pieces to the integrated sleeves of the fronts, from the slit mark to the corner (seam number 3). Press the seam allowances open.

Step 9 — Sleeve vents with zip

Turn in top ends of zip tapes of the 12 cm (5 in) long zips. Lay each zip tape face down on edge of opening (on right fabric side) so that teeth of zip lie on garment piece and turned in end of zip tape meets the marked hem line. Stitch the zip tape in place along the marked seam line, close to teeth of zip, from the lower edge to approx. 1 cm (3/8 in) before end of vent. Open the zip. Stitch the second zip tape to remaining edge of vent in same manner.

Step 10 — Seam allowance

Clip the seam allowance of the back into the top corners (seam number 4), toward end of seam. Press the seam allowances open. Stitch the under sleeve pieces to the integrated sleeves of the back, up to the corner (seam number 4). Then stitch the under sleeve pieces to the armhole edges of the side pieces, from corner to corner.

Step 11 — Sleeve hem

Press sleeve hem allowances to inside and sew in place by hand.

Step 12 — Front edges with zip, neck edge

Separate the zip halves. Turn in top ends of zip tapes. Pin halves of zip face down on front edges, from neck edge (on right fabric side), so that teeth of zip lie on garment piece and zip tape lies on seam allowance. Stitch zip tapes to seam allowances. Stitch shoulder seams of facing. Pin facing right sides together with jacket, catching zip. Stitch along front edges and neck edge. Trim seam allowances and clip allowances of facing into corners. Turn the facings forward and up and stitch to seam allowance as far as possible, close to seam. Turn the facing to the inside and press the edges.

Step 13 — Hem

At the hem edge, turn facings forward again. Press hem allowance to inside but do not yet sew. Turn facings to the inside again.

Step 14 — Sew lining

On back lining pieces, stitch allowances of centre seam together, 1 cm (3/8 in) from edge. For the ease pleat, stitch along centre back at the top and bottom, each 5 cm (2 ins) long, and baste in between. Press the pleat to one side. Stitch darts, pleats, and seams of lining.

Step 15 — Line jacket, hem

Stitch lining to inside facing edges, turning hem allowance down. Lay lining inside jacket with wrong sides together, pulling linings into sleeves. Turn hem allowance to inside and sew in place by hand. Turn in lining along lower edge of jacket. Press fold edge lightly, push upward in a shallow curve, and pin to hem allowance. Sew facings and lining in place. Lay extra length of lining down and press lightly. Turn in edges of sleeve linings and sew to hem allowances. Turn extra length down and press. Turn in the sleeve linings and sew to the hem allowances and the zip tapes.

Step 16 — Pleat

Work from the right side to stitch fronts along line of pleat seam, approx. 3 cm (1 1/4 ins) long, beginning at neck edge.

Step 17 — Shoulder tabs

Fold each shoulder tab lengthwise, right side facing in. Stitch the long edges together with zigzag stitching. Lay seam along centre of tab. Stitch lower end closed. Turn tabs right side out and press edges. Stitch across the tab, 4 cm (1 5/8 ins) above the lower end. Above this crosswise line of stitching, topstitch along lengthwise centre of tab. Neaten end of tab or bind with a bias strip of lining fabric. Lay tabs on the shoulder seams and upper sleeve seams so that upper ends of tabs extend past neck edge, approx. 3 cm (1 1/4 ins) wide. Pin the tabs in place along the lengthwise centres and sew to seams by hand. At neck edge, fold extending ends of tabs to inside of jacket and sew in place by hand.

BurdaStyle

10/2011 Plus size zip up jacket