

106 Top

Sizes 34, 36, 38, 40, 42

Back length approx. 50 cm (20 ins)

3/4-sleeves, approx. 17 cm (7 ins) shorter than normal

Materials

Natté,

width: 145 cm (57 ins)

length: 1.25 – 1.25 – 1.25 – 1.30 – 1.30 m (1 1/2 yds).

Vilene/Pellon G 785.

3 large sew-on snap fasteners.

Recommended fabrics: Fabrics with some body.

Preparations

Print the pattern out on letter or A4 sized paper. It is **very important** to not scale or fit any of the pages, you must print the document in **actual size**. Your pattern will print on multiple pages, which you will then tile together. Arrange the sheets on a large, hard and flat surface matching up the numbers and letters (i.e. 6A to 6A). Cut and fold one of the sides and match the edge to its corresponding side. Then, tape down in place so paper is secure.



Trace the pattern pieces from the pattern sheet following the lines and markings for the correct size and the correct style (106). This pattern also includes pattern pieces, lines and markings for style 107 that should be ignored.

On back piece, note different lines for right shoulder seam and left fastening underlap but cut both halves of the back the same size initially, from the double layer of fabric. Then, for the right shoulder seam, trim the self-facing to 1.5 cm (5/8 in) before the marked "right seam" line.


burda style magazine patterns do not have seam allowance included.

To be added:

Seams and edges 1.5 cm (5/8 in), hem 4 cm (1 5/8 ins), sleeve hems 4 cm (1 5/8 ins) (flare sleeve hem allowance).



Fold the fabric as shown in the pattern layout. Right side faces in on a double layer of fabric; right side faces up on a single layer of fabric. Lay asymmetric pieces 3 and 4 on right fabric side, with their printed sides facing up.



Cutting Out

1 front, on a fold	1x
2 back, on a fold	1x
3 front facing	1x
4 back facing	1x
5 sleeve	2x
6 collar, on a fold	2x

Interfacing: See shaded area on pattern layout. Iron interfacing to wrong side of under collar piece. Fuse interfacing to wrong side of fabric.

Sewing

Stitch right shoulder seam, right sides together. Stitch shoulder seam of facing (seam number 2). Press seam allowances open.

Stitch the collar pieces right sides together along the outer edges. Trim seam allowances. Turn collar right side out and press. Baste joining edges of collar together to neck edge (seam number 3).

Neck, shoulder fastening, and left shoulder seam: Pin facing right sides together with neck edge, left front fastening edge, and integrated back underlap. Stitch along back underlap edge, neck edge, and front fastening edge, up to marking. Trim seam allowances. Turn side facing ends back and pin. Stitch left shoulder seam up to marking. Remove pins. Turn facing to inside. Press edges. Press shoulder seam allowances open. On inside, stitch side end of front facing to side underlap end.

Stitch sleeves to front and back between markings. Turn extending sleeve seam edges up at each seam end and pin. Stitch side seams from sleeve joining seams to lower edge. Remove pins. Stitch sleeve seams. Press seam allowances forward.

Press hem allowances on shirt and sleeves, to inside and sew in place by hand.

Sew top halves of snap fasteners to inside of left front fastening edge, evenly spaced, not exiting needle on right fabric side. Sew bottom halves of snaps to underlap to match.

