

130 Top

Sizes 36, 38, 40, 42, 44

Back length approx. 73 cm (29 ins)

Materials

Stretch jersey,
width: 150 cm (59 ins)
length: 1.80 – 1.80 – 1.80 – 1.85 – 1.85 m
(2 – 2 – 2 – 2 1/8 – 2 1/8 yds).

Vilene/Pellon G 785.

Recommended fabrics: Stretch jersey. Use only stretch fabrics with two “good” sides.

Preparations



Print the pattern out on letter or A4 sized paper. It is **very important** to not scale or fit any of the pages, you must print the document in **actual size**. Your pattern will print on multiple pages, which you will then tile together. Arrange the sheets on a large, hard and flat surface matching up the numbers and letters (i.e. 6A to 6A). Cut or fold one of the sides and match the edge to it’s corresponding side. Then, tape down in place so paper is secure.

Trace the pattern pieces from the pattern sheet following the lines and markings for your size.


burda style magazine patterns do not have seam allowance included.

To be added:

Seams and edges 1.5 cm (5/8 in), no allowances on hem and sleeve hem edges and no allowances on lower edges of flounces.



Fold the fabric as shown in the pattern layout. Right side faces in on a double layer of fabric; right side faces up on a single layer of fabric. Lay the asymmetric pieces 3 and 4 on the right side of the fabric, with their printed sides facing up.



Cutting Out

1 upper front, on a fold	1x
2 lower front, on a fold	1x
3 lower flounce	1x
4 upper flounce	1x
5 back, on a fold	1x
6 front sleeve	2x
7 back sleeve	2x
8 front neck facing, on a fold	1x
9 back neck facing, on a fold	1x

Interfacing: Iron to wrong side of facing pieces.

Sewing

Note: Stitch seams on stretch fabrics with a special stretch stitch or at a narrow zigzag setting.

Lay lower flounce on lower front piece, with wrong side facing right side and matching centres. Baste to upper edge and to left side seam edge. On right side seam edge, baste flounce to front, from upper edge to seam mark/ fold line. Stitch lower front to upper front. Press seam allowances up.

Fold lower flounce up on marked fold line. Baste to right side seam edge and to right armhole edge, up to seam mark at seam number 2. Lay upper flounce on right half of front, over lower flounce, with wrong side facing right side. Baste to side seam edge, armhole edge and neck edge.

Stitch side seams, right sides together. Stitch upper sleeve seams and lower sleeve seams.

Stitch sleeves to armhole edges. Press allowances toward sleeves, above underarm curve.

Stitch shoulder seams of facing. Stitch facing to neck edge, right sides facing. Trim seam allowances. Turn facing up and stitch to seam allowances, close to seam. Turn facing to inside and sew to seams.

