

### 130 Trousers

Sizes 36, 38, 40, 42, 44

Side length: 113 cm (44 1/2 ins)

Upper edge of waistband = waist

Hem circumference 52 cm (20 1/2 ins)

### Materials

**Heavyweight jersey,**

width: 150 cm (59 in)

length: 1.50 – 1.50 – 1.55 – 1.55 – 1.55 m (1 3/4 yds).

A piece of lining, 30 x 30 cm (12 x 12 ins).

Interfacing.

6 hammer-on snap fasteners.



**Recommended fabrics:** Trousers fabrics.

### Preparations


Print the pattern out on letter or A4 sized paper. It is very important to not scale or fit any of the pages, you must print the document in actual size. Your pattern will print on multiple pages, which you will then tile together. Arrange the sheets on a large, hard and flat surface matching up the numbers and letters (i.e. 6A to 6A). Cut or fold one of the sides and match the edge to it's corresponding side. Then, tape down in place so paper is secure.

Trace the pattern pieces from the pattern sheet following the lines and markings for the correct size and the correct style (130). This pattern also includes pattern pieces, lines and markings for style 130A that should be ignored.

Trace the pocket piece from piece 21 as a separate pattern piece – it is the same for all sizes. Note different lines on back waistband for right side seam and left underlap, but cut both halves of waistband the same, initially, from the double layer of fabric. The stitching line on piece 21 is marked for size 36. For sizes 38 – 44, remark the stitching line according to the size lines. The snap fasteners marked on pieces 21 and 24 are for size 36. For remaining sizes, earmark the snaps according to the size lines.



Cut from a double layer of fabric, right side facing in. Use fabric with a width of 150cm.



### Cutting Out

- 21 front trouser piece 2x
- pocket piece 1x
- 22 back trouser piece 2x
- 23 left slit underlap 1x
- 23 left slit facing 1x
- 24 front waistband, on a fold 2x
- 25 back waistband, on a fold 2x

Lining: pocket piece (piece 21) and underlap (piece 23).

Interfacing: See shaded area on pattern layout. Fuse interfacing to wrong side of fabric.

**burda style magazine patterns do not have seam allowance included.**

To be added:

Seams and edges 1.5 cm (5/8 in),  
hem 3 cm (1 1/4 ins).

## Sewing

Stitch back darts and press toward centre. Stitch right side seam, not stitching across pocket opening. Press seam allowances open.


**In-seam pocket (right):** Pin pocket pieces right sides together with seam allowances of pocket opening edges – pocket lining piece in front and fabric pocket piece in back. Stitch pocket pieces in place – along seam line on pocket opening edge and close to side seam above and below pocket opening. Press pocket lining piece onto front. Topstitch front pocket opening edge as marked. Press fabric pocket toward front. Stitch pocket pieces together and baste upper edge in place.

Stitch left side seam below slit mark.

Lay underlap pieces of outer fabric and lining right sides together. Stitch together along outer edge (rounded vertical edge), leaving joining edge and upper end open. Turn underlap right side out and press. Stitch underlap to back edge of opening, turn forward, and press allowances onto trouser piece. Pin left slit facing to slit edge of left front trouser piece and stitch in place, up to slit mark. Turn slit facing to inside. Topstitch front slit edge as marked. Lay slit closed and topstitch bottom end again in line of previous stitching, catching underlap.

Stitch inside leg seams, right sides together. Pull one trouser leg into the other, right sides facing. Stitch front and back centre seam as continuous seam. Press centre seam open, from each upper edge to beginning of curve. Do not press seam allowances flat along curve.

**Waistband:** Stitch right side seam on waistband units, stitching inside and outside waistband units as mirror images. Stitch outside waistband unit to upper trouser edges, leaving front waistband end extending and stitch back waistband end to slit underlap. Press seam allowances onto waistband. Lay remaining waistband unit right sides together with attached waistband, and pin. Trim extending front waistband end to width of seam allowance. On ends of waistband,



turn allowance on inside edge up. Stitch across waistband ends and along upper waistband edge. Turn inside waistband edge under, approx. 4 cm (1 5/8 ins) long, and baste, then lay remaining edge flat over joining seam, without turning under. Work from right side to stitch along joining seam, catching inside edge.

Press hem allowances to inside, turn in, and stitch by hand.

Insert top halves of snaps to left slit edge and to waistband, as marked. Mark position of bottom halves of snaps on underlap and waistband. Insert bottom halves as marked.