

130 Trousers

and cummerbund

Burda sizes 72, 76, 80, 84, 88

Side length with waistband 109 cm (43 ins)
(upper waistband edge = waist)

Hem circumference 58 cm (23 ins)

Materials

Trousers: Wool Crêpe,
width: 150 cm (59 ins)
length: 1.50 – 1.50 – 2.00 – 2.00 – 2.00 m
(1 3/4 – 1 3/4 – 2 1/4 – 2 1/4 – 2 1/4 yds).

A piece of lining, approx. 45 x 30 cm (18 x 12 ins),
for pocket pieces.

Interfacing.

Satin ribbon, 2.5 cm (1 in) wide and 2.25 m (2 5/8 yds).

1 zip, 18 cm (7 ins) long.

1 hammer-on trouser hook fastener and 1 flat inside button.

Cummerbund: Duchesse,
width: 150 cm (59 ins)
length: 0.80 – 0.85 – 0.90 – 0.90 – 0.95 m
(7/8 – 1 – 1 – 1 – 11/8 yds).



Interfacing.

Hook-and-eye fastening tape: 0.15 m.

Recommended fabrics: Trousers fabrics of wool or blends. Duchesse for the cummerbund.

Preparations


Print the pattern out on letter or A4 sized paper. It is very important to not scale or fit any of the pages, you must print the document in actual size. Your pattern will print on multiple pages, which you will then tile together. Arrange the sheets on a large, hard and flat surface matching up the numbers and letters (i.e. 6A to 6A). Cut or fold one of the sides and match the edge to it's corresponding side. Then, tape down in place so paper is secure. Trace the pattern pieces from the pattern sheet following the lines and markings for your size.



Wool Crêpe, 150cm wide

Sizes 72, 76

fabric fold




Right side faces in on a double layer of fabric; right side faces up on a single layer.

Duchesse, 150cm wide


Sizes 72-88

selvage



Sizes 80-88

fabric fold



selvage

The stitching line at the zip slit is marked for size 72. For sizes 76 – 88, mark the stitching line the same distance from centre front as for size 72. Seam and hem allowances:

burda style magazine patterns do not have seam allowance included.

Seam and hem allowance to be added:

Seams and edges 1.5 cm (5/8 in), hem 4 cm (1 5/8 ins).

Cutting Out

Trousers

Wool crêpe:

- 21 front trouser piece 2x
- 22 side hip yoke with integrated pocket piece 2x
- 24 back trouser piece 2x

Draft the following pieces NOT included in the pattern:

- a) left underlap piece, 19 cm (7 1/2 ins) long, 6 cm (2 1/2 ins) wide, finished width 3 cm (1 1/4 ins),
- b) right waistband, with 6.5 cm (2 5/8 in) overlap, 42.5 – 44.5 – 46.5 – 48.5 – 50.5 cm (16 3/4 – 17 1/2 – 18 1/4 – 19 1/8 – 20 ins) long; left waistband, with 3.5 cm (1 1/2 in) underlap, 39.5 – 41.5 – 43.5 – 45.5 – 47.5 cm (15 5/8 – 16 3/8 – 17 1/8 – 18 – 18 3/4 ins) long, each 7 cm (3 ins) wide, finished width 3.5 cm (1 1/2 ins).

Lining: pocket piece (piece 23) 2x.

Interfacing: See shaded area on pattern layout.

Cummerbund

Duchesse:

- c) cummerbund (top side), cut on bias, 70 – 74 – 78 – 82 – 86 cm (27 3/4 – 29 1/4 – 30 3/4 – 32 1/2 – 34 ins) long, 36 cm (14 1/4 ins) wide,
- d) cummerbund (underside), cut on bias, 70 – 74 – 78 – 82 – 86 cm (27 3/4 – 29 1/4 – 30 3/4 – 32 1/2 – 34 ins) long, 12 cm (4 3/4 ins) wide.

Interfacing: See shaded area on pattern layout.

Sewing

Trousers

On back trouser pieces, stretch inside leg seam edges above seam mark.

Stretch seam edges: Lay back trouser pieces right sides together. Press inside leg edges above seam mark, with a steam iron or under a damp cloth until they match corresponding edge on trouser front.



Press creases in front trouser pieces. Fold pleats in direction of arrows and baste.

Hip yoke pockets: Stitch pocket pieces right sides together with pocket opening edges of front trouser pieces. Turn pocket pieces up and stitch to seam allowances, close to seam. Turn pocket pieces to inside. Pin pocket opening edges to side hip yokes, at placement lines. Stitch edges of pocket pieces together. Baste pocket pieces to wrong side of front trouser pieces, first trimming away allowance of right pocket piece, along centre front.

Stitch back darts. Press darts toward centre.

Stitch side seams. Press seam allowances open. Pin satin ribbon to trousers, over side seams. Edgestitch ribbons in place.

Stitch inside leg seams. Stitch centre front seam from slit mark to inside leg seam.

Zip slit: Press self-facings on slit edges to inside. On right edge, stitch along centre front and on left edge, stitch 5 mm (3/16 in) before centre front. Stitch zip under left slit edge (underlap), close to zip teeth. Pin slit closed, matching centre fronts. Stitch loose zip tape to right facing, not catching trouser piece. Baste facing in place. Topstitch slit as marked, from upper edge to 3 cm (1 1/4 ins) before end. Fold underlap piece lengthwise and stitch across bottom end. Turn right side out. Lay underlap under left slit edge and pin to facing. Stitch slit facing to underlap, close to zip attachment seam. Lay slit closed again and topstitch to the end, catching underlap.

Waistband and centre back seam: Fold waistband pieces in half lengthwise, wrong side facing in, and press upper waistband edge. Unfold waistband pieces again. Stitch right and left waistband to upper edges of trousers, with waistband overlap extending on the right and stitching waistband underlap to slit underlap on the left. Press seam allowances onto waistband pieces. Stitch centre back seam on trousers and waistband. Press seam open, from upper edge to beginning of crotch curve. Attach trousers hook to inside waistband half, 1 cm (3/8 in) from right waistband end. Fold ends of waistband, right side facing in. On left waistband end, turn allowance of inside edge up. Stitch across left waistband end. On overlap, on right end, turn

Sewing Continued...

seam allowances down again and stitch along lower overlap edge and across right waistband end. Turn waistband right side out. On front, turn inside waistband edge under, approx. 4 cm (1 5/8 ins) long and baste, then lay remaining edge flat over attachment seam. Working from outer side, stitch along waistband attachment seam, catching inner edge. Work a buttonhole in left waistband end. Sew button to inside of waistband. Attach bar of trousers fastener to waistband, to match hook.

Press hem allowances to inside and sew in place by hand.

Press creases in back trouser pieces. Repress creases in front hem edges.

Cummerbund

On top waistband piece, gather short edges to 12 cm (4 3/4 ins). Lay this piece right sides together with interfaced underside piece. Pin and stitch edges together, leaving a section of seam open, for turning. Trim seam allowances, trimming corners diagonally. Turn waistband right side out. Sew opening closed. Press pleats lightly. Stitch hook tape to one waistband end and eyelet tape to wrong side of other end, first turning ends of tapes under.