

112 Trousers

Burda sizes 34, 36, 38, 40, 42, 44

Side length from waist 107 cm (42 1/4 ins)

Waist is 7 cm (2 3/4 ins) above waistband attachment seam

Hem circumference 40 cm (16 ins)

Materials

Cotton jersey,
width: 150 cm (59 ins)
length: 1.50 m (1 3/4 yds) for all sizes.

A piece of lining, approx. 35 x 30 cm (14 x 12 ins), for the pocket pieces.

A twin sewing machine needle.

Recommended fabrics: Jersey. Use stretch jersey fabrics only. Fabrics with some elastane are ideal.




Preparations

Print the pattern out on letter or A4 sized paper. It is **very** important to not scale the document. Your pattern will print on multiple pages, which you will then tile together. Arrange the sheets on a large, hard and flat surface matching up the numbers and letters (i.e. 6A to 6A). Cut or fold one of the sides and match the edge to its corresponding side. Then, tape down in place so paper is secure.

Trace the pattern pieces from the pattern sheet following the lines and markings for style 112 and your size. Trace the pocket piece from piece 1 as a separate pattern piece – it is the same for all sizes.

burda style magazine patterns do not have seam allowance included.

Seam and hem allowance to be added:
Seams and edges 1.5 cm (5/8 in), hem 4 cm (1 5/8 ins).



Cut from a double layer of fabric, right side facing in.

Cutting Out

Jersey:

- 1 front trouser piece 2x
- pocket piece 2x
- 2 back trouser piece 2x

Draft the following piece NOT included in the pattern:

- a) waistband, 64 – 68 – 72 – 76 – 80 – 84 cm (25 1/4 – 26 3/4 – 28 1/2 – 30 – 31 1/2 ins) wide and 40 cm (16 ins) wide, finished width 20 cm (8 ins).

Lining: pocket piece (piece 1).

Sewing

Stitch side seams, not stitching across pocket openings. Press seam allowances open.

Inseam pockets: Work from inside to pin pocket pieces to seam allowances of pocket opening edges, right sides together. Stitch in place directly along marked seam lines. Above and below pocket openings, stitch pocket pieces in place, close to seam. Press pocket pieces forward and stitch together. Baste upper pocket edges in place. Stitch pocket lining pieces to pocket opening edges of trouser fronts. Omit stitching at pocket opening ends.

Stitch inside leg seams, stretching trouser backs above seam marks.

Pull one trouser leg into other, right sides facing. Stitch centre front and back seam as continuous seam. Press seam open from upper edges to beginning of crotch curve. Do not press allowances flat along curve.

Stitch waistband ends together (= centre back seam). Press seam open. Mark centre front opposite seam. Fold waistband in half, wrong side facing in. Stitch waistband edges together to upper trousers edge, stretched to fit. Neaten seam allowances and press down.

Turn hem allowances to inside. Work from right side and use twin machine needle to stitch hem 3 cm (1 1/4 ins) from lower edge

