

Cutting and Sewing Instructions

107 A, B, C Skirts

Burda sizes 34, 36, 38, 40, 42 Length of skirt from waist:

A, 48 cm (19 ins); B, 56 cm (22 1/4 ins); C, 68 cm

(26 3/4 ins)

Upper edge of skirt sits 7 cm (2 3/4 ins) above waist

Materials

Recommended fabrics: Skirt fabrics with some body, with or without elastane.

View A:

- 135 cm (53 in) wide canvas: 0.75 m (7/8 yd) for all sizes.
- 140 cm (55 in) wide lining: 0.60 m (3/4 yd).
- Interfacing: Vilene/Pellon G 700.
- 1 invisible zip, 40 cm (16 ins) long, and a special presser foot.

View B:


- 140 cm (55 in) wide crosswise stretch poplin: 0.85 m (1 yd) for all sizes.
- 140 cm (55 in) wide lining: 0.70 m (7/8 yd).
- Interfacing: Vilene/Pellon G 700.
- 1 invisible zip, 40 cm (16 ins) long, and a special presser foot.

View C:

- 135 cm (53 in) wide organza with taffeta appliqués: 1.00 m (1 1/8 yds) for all sizes.
- 140 cm (55 in) wide lining: 0.85 m (1 yd). Interfacing: Vilene/Pellon G 700.
- 1 invisible zip, 40 cm (16 ins) long, and a special presser foot.

Preparations


Print the pattern out on letter or A4 sized paper. It is **very** important to not scale the document. Your pattern will print on multiple pages, which you will then tile together. Arrange the sheets on a large, hard and flat surface matching up the numbers and letters (i.e. 6A to 6A). Cut or fold one of the sides and match the edge to it's corresponding side. Then, tape down in place so paper is secure.



Trace the pattern pieces from the pattern sheet following the lines and markings for style 107 and your size. Note different hem lines for views A, B, and C.

burda style magazine patterns do not have seam allowance included.

Seam and hem allowance to be added: Seams and edges 1.5 cm (5/8 in), hem 4 cm (1 5/8 ins), lining 1.5 cm (5/8 in).



Cutting Out

Views A, B, C Outer fabric:

21 front skirt panel, on a fold 1x

22 centre back skirt panel 2x

23 side back skirt panel 2x

24 front facing, on a fold 1x

25 back facing 2x

Lining: pieces 21 to 23.

Interfacing: See pattern layout.



Cutting and Sewing Instructions

Sewing

Views A, B, C

Stitch front darts. Press darts toward centre. Stitch section seams on skirt backs. Stitch side seams on skirt and facing. Press seam allowances open.

Sew invisible zip to centre back edges, see the "Helpful Hint". Stitch centre back seam from lower edge to zip.


Stitch darts and seams of lining. Leave slit for zip open, 2 cm (3/4 in) longer than on skirt. Baste facing to upper edge of skirt lining, with wrong side facing right side. Stitch lower edge of facing in place.

Upper edge of skirt: Place lining and facing over skirt, with right sides together, and pin to upper edge of skirt. At zip opening, turn ends of facing back, about 5 mm (3/16 in) before edge of opening, and pin to upper edge. At slit edges of skirt, turn allowances to outside and pin to upper edge of skirt, over facing. Stitch along upper edge of skirt. Turn allowances on opening edges to inside. Lay facing and lining up. Stitch facing to seam allowances, as far as possible, close to seam. Turn facing and lining to inside and sew to zip tapes.


Press hem allowance to inside and sew in place by hand. Hem lining so that it is about 2 cm (3/4 in) shorter than skirt.

View A Canvas, 135 cm wide


Cut from a double layer of fabric, right side facing in.



View B Poplin, 140 cm wide




View C Organza, 135 cm wide





Invisible Zipper Helpful Hint



These special zippers come in various lengths. The zipper should be at least 2 cm (3/4 in) longer than the slit. It is sewn in place before the seam below the slit is stitched. A special presser foot is required to sew the zipper in place.

Sewing the zipper in place:

Open the zipper and push the coil back with your thumbnail to reveal the seam marking between the tape and the coil. Place the open zipper right side down on the right fabric side of one slit edge.

In order to stitch the zipper in place exactly along the marked seam line, you must first calculate the distance between the tape edge and the fabric edge as follows: width of seam allowance minus 1 cm (3/8 in) tape width = distance from edge of fabric. This will yield a value of 5 mm (3/16 in) if the width of the seam allowance is 1.5 cm (5/8 in).

Pin the top end of the zipper tape in place, the calculated distance from the edge of the fabric. The bottom end of the zipper will extend past the marked end of the slit. Place the presser foot on the zipper so that the coil is in the notch to the right of the needle (1). Stitch zipper in place, from the top to the marked end of the slit. Close zipper.

Place the other zipper tape face down on the opposite slit edge and pin in place at the top. Open zipper again. Place the presser foot on the top end of the zipper so that the coil is in the notch to the left of the needle (2). Sew the zipper in place, from the top to the end of the slit. Close zipper.

Now stitch the seam below the zipper, from bottom to top. Turn the loose lower end of the zipper out of the way, over the seam allowance. Stitch as close as possible to the last stitches of the zipper seams. Trim away excess zipper and bind the end with a scrap of fabric.



Additional Information:

Burda patterns do not include seam and hem allowances. We recommend adding 1-2 cm (3/8 - 3/4 inch) for seams and 2-5 cm (3/4 - 2 inch/es) for hems. Refer to your specific pattern instructions for exact measurements.

The fabric requirements are based on the fabric used for the original designs. These amounts will change if you use fabric of a different width. The pattern of the fabric determines whether all the pieces must be cut in the same direction or whether some can be reversed to save fabric.

The cutting layout printed with the instructions shows the best way to place the pattern pieces on our original fabric. Fold the fabric double with the right side facing in. The fabric then has a fold edge and a selvedge edge. When cutting from a single fabric layer, the right side should face up.

Pattern pieces which are shown in the cutting layout with broken outlines should be pinned to the fabric with their printed side facing down.

Grey shaded areas in the cutting layout indicate which pieces are to be interfaced.

Transfer the pattern piece lines to the wrong side of your fabric with dressmaker's carbon paper. Hand-baste along lines (e.g. for pockets or centre front) to make them visible on the right side of the fabric.

Have fun sewing, and make sure to upload pictures of your finished sewing project to BurdaStyle.com/projects and link it to the pattern you made it from!

If you have any questions about the pattern or specific instructions please email answers@burdastyle.com and your inquiry will be forwarded to one of our sewing pattern experts.

Fabrics may shrink when laundered for the first time, especially those made of cotton, linen, and rayon. To avoid shrinkage of the finished garment, these fabrics should be pre-treated (washed and dried before cutting out the fabric pieces). Use the temperature settings you plan to use for the finished garment. If you want to test the amount of shrinkage of your fabric, cut a square of the fabric and measure it exactly. Finish the edges, then wash it, and compare the size after washing with the original size.

Symbols

Armhole markings

These small lines at the edges of the sleeve and front armhole pieces must meet when the sleeve is set in.



Broken line

In the cutting layout, the broken line indicates the fold edge of a double layer of fabric.



Button

Buttonhole



Fold line

In the pattern overview box, this broken line means that the pattern edge must be placed on a fold and not cut.



Joining line

Large pattern pieces that cannot fit on the pattern insert sheet will be in two pieces. These pieces must be taped together after they have been traced onto pattern paper. A double line indicates the joining line and small triangles indicate match points.



Lengthening

If a pattern piece is too long to fit on the pattern insert sheet, you will need to lengthen it when you trace the pattern piece onto pattern paper. Lengthen the pattern from the point of the arrow by the amount indicated in centimeters at the arrow.



Pleat symbol

Fold the pleat in the direction of the arrow.



Presser foot

A presser foot image indicates seam and topstitching lines.



Scissors indicate slash lines, such as welt pocket openings. (On downloadable patterns, scissors indicate edges to be cut without an added seam allowance.)



Seam marks

Shown on long seams, these small lines perpendicular to the cutting line indicate edges to be matched. Match the seam marks to one another.



Seam numbers

Adjacent pattern pieces that must be sewn together are indicated with the same seam numbers. Match pieces with the same numbers.



Slit/Placket mark

This small, thick line that intersects the cutting line indicates beginning or end of a slit or placket.



The following symbols will only be found on the pattern pieces in the pattern overview box. On the pattern insert sheet and on the downloadable pattern pieces, the words are written out.

BurdaStyle For People Who Sew














For the best fit, it's important to take precise measurements. Measure your body while wearing underwear or close-fitting garments, and have someone assist you if needed. Use a flexible measuring tape to measure around your body, ensuring the tape is taut but not tight and parallel to the floor. Stand upright with a relaxed posture, and breathe normally while you measure.

- **1** Bust: Measure around the fullest part of your bust. Neck circumference: Measure the circumference at the base of the neck and above the collarbone.
- **2** Waist: Measure around your natural waist, the narrowest part. **Hips:** Measure horizontally around the fullest part of your bottom and upper thighs. **Additional measurements:**
- **3** Front waist length: Measure from the side base of the neck over the apex of the bust to the natural waistline. **Bust depth:** Measure from the side base of the neck to the apex of the bust.

Important: Compare your body measurements to the appropriate Burda size chart here or on BurdaStyle. com. Circle each of your body measurements on the size chart since you may want to adjust your pattern to fit a range of sizes. Your Burda size will be different from your regular store-bought clothing size.

- **4** Back waist length: Measure from the base of your neck to the natural waistline. Back width: Measure horizontally between your arm attachment points.
- **5** Shoulder: Measure from the base of your neck to the tip of your shoulder. **Upper arm:** Measure around the fullest part of your upper arm.
- **6** Arm length: With your arm slightly bent, measure from the tip of your shoulder over the elbow to the natural waistline.

| INFANTS' AND | TODDLER | S' SIZE | CHAR | Γ (based | d on he | ight) i | nches | | | | |
|--------------|---------|---------|-------|----------|---------|---------|-------|--------|-------|-------|--------|
| BURDA SIZE | 56 | 62 | 68 | 74 | 80 | 86 | 92 | 98 | 104 | 110 | 116 |
| US size | newborn | 3mo | 6mo | 12mo | 18mo | 2T | 3T | 4T | 5 | 6 | 6x |
| CHEST | 17¾ | 181/2 | 191/4 | 20 | 21 | 21¾ | 221/2 | 23 | 231/4 | 231/2 | 23% |
| WAIST | 161/2 | 17³/s | 181/8 | 181/8 | 9¾ | 20 | 201/2 | 21 | 211/4 | 21¾ | 22 |
| HIP | 181/8 | 18¾ | 19¾ | 201/2 | 211/4 | 22 | 23 | 231/4 | 24 | 24¾ | 251/4 |
| BACK LENGTH | 61/2 | 6¾ | 7 | 71/2 | 8 | 85/8 | 9 | 91/2 | 91/8 | 101/2 | 101/8 |
| ARM LENGTH | 61/2 | 71/2 | 81/4 | 9 | 101/2 | 111/4 | 121/4 | 131//8 | 141/8 | 151/8 | 161/8 |
| NECK | 85/8 | 9 | 91/2 | 91/8 | 91/8 | 10 | 101/8 | 101/8 | 11 | 11 | 113//8 |

| WOMEN'S SIZE CHART (Regular) inches | | | | | | | | | | | | | | | |
|-------------------------------------|-------|-------|-------|--------|--------|--------|--------|-------|-------|-------|-------|-------|-------|-------|-------|
| BURDA SIZE | 32 | 34 | 36 | 38 | 40 | 42 | 44 | 46 | 48 | 50 | 52 | 54 | 56 | 58 | 60 |
| HEIGHT | 661/4 | 661/4 | 661/4 | 661/4 | 661/4 | 661/4 | 661/4 | 661/4 | 661/4 | 661/4 | 661/4 | 661/4 | 661/4 | 661/4 | 661/4 |
| BUST | 30 | 311/2 | 33 | 34¾ | 361/4 | 373/4 | 391/2 | 41 | 431/2 | 451/2 | 48 | 501/2 | 52¾ | 551/4 | 571/2 |
| WAIST | 23 | 241/2 | 26 | 273/4 | 291/4 | 30¾ | 321/2 | 34 | 361/4 | 38¾ | 41 | 431/2 | 451/2 | 48 | 501/2 |
| HIP | 321/2 | 34 | 351/2 | 37 | 38¾ | 401/4 | 41¾ | 431/2 | 451/2 | 48 | 501/2 | 523/4 | 551/4 | 571/2 | 60 |
| BACK LENGTH | 15¾ | 16 | 161/4 | 161/2 | 165/8 | 16¾ | 17 | 171/8 | 171/4 | 171/2 | 173/4 | 18 | 181/4 | 181/2 | 181/2 |
| SLEEVE LENGTH | 231/4 | 231/4 | 231/4 | 23¾ | 23¾ | 24 | 24 | 24 | 24 | 241/2 | 241/2 | 243/4 | 243/4 | 243/4 | 243/4 |
| NECK WIDTH | 13 | 133/8 | 13¾ | 141/8 | 141/2 | 15 | 153/8 | 15¾ | 161/8 | 161/2 | 17 | 171/4 | 173/4 | 181/8 | 181/2 |
| SIDE LEG | | | | | | | | | | | | | | | |
| LENGTH | 39¾ | 401/4 | 401/4 | 40¾ | 41 | 41 | 411/2 | 411/2 | 411/2 | 41¾ | 413/4 | 41¾ | 421/4 | 421/2 | 421/2 |
| FRONT WAIST | | | | | | | | | | | | | | | |
| LENGTH | 161/2 | 17 | 171/4 | 173/4 | 181/8 | 181/2 | 19 | 191/4 | 19¾ | 201/4 | 201/2 | 21 | 211/4 | 213/4 | 221/4 |
| BUST POINT | 91/2 | 91/8 | 101/4 | 103/4 | 111//8 | 111/2 | 111//8 | 121/4 | 123/4 | 13 | 131/2 | 141/4 | 141/2 | 143/4 | 15 |
| UPPER ARM | | | | | | | | | | | | | | | |
| CIRCUMFERENCE | 91/8 | 101/4 | 10¾ | 111//8 | 111/2 | 111//8 | 121/4 | 12¾ | 131/2 | 141/2 | 15 | 15¾ | 161/2 | 171/4 | 181/4 |

| MEN'S SIZE CHART (Regular) inches | | | | | | | | | | |
|-----------------------------------|-------------|-------|-------|-------|-----|-------|-------|--|--|--|
| BURDA SIZ | E 44 | 46 | 48 | 50 | 52 | 54 | 56 | | | |
| HEIGHT | 661/4 | 671/4 | 681/2 | 69¾ | 71 | 71¾ | 72½ | | | |
| CHEST | 34% | 361/4 | 37¾ | 391/4 | 41 | 421/2 | 44 | | | |
| WAIST | 30¾ | 321/4 | 34 | 35½ | 37 | 38½ | 41 | | | |
| SEAT | 35½ | 37 | 38½ | 40 | 40¾ | 43½ | 451/4 | | | |
| BACK LENGTH | 16½ | 17 | 171/4 | 17½ | 17¾ | 18 | 181/4 | | | |
| ARM LENGTH | 24 | 241/2 | 24¾ | 251/4 | 25½ | 26 | 26½ | | | |
| NECK | 14½ | 15 | 151/4 | 15¾ | 16 | 16½ | 17 | | | |

WOMEN'S SIZE CHART (Petite) inches

* These sizes are Burda petite sizes and differ in height from the regular sizes. The height measurements are from 63 to 66¼ inches. If you are taller than 66¼ inches, you can make alterations to the length of the garment, the sleeve length, etc. to fit your measurements.

| Joan measarements. | | | | | | | | |
|--------------------|-------|-------|-------|-------|-------|---------|-------|-------------------|
| BURDA SIZE | 16 | 17 | 18 | 19 | 20 | 21 | 22 | 23 |
| HEIGHT | 63 | 63 | 63 | 63 | 63 | 63 | 63 | 63 |
| BUST | 30 | 311/2 | 33 | 34¾ | 361/4 | 37¾ | 391/2 | 41 |
| WAIST | 23 | 241/2 | 26 | 27¾ | 291/4 | 30¾ | 321/2 | 34 |
| HIP | 321/2 | 34 | 351/2 | 37 | 38¾ | 401/4 | 41¾ | 431/2 |
| BACK LENGTH | 15 | 151/4 | 15¾ | 15¾ | 16 | 161/8 | 161/4 | 16³/ ₈ |
| SLEEVE LENGTH | 221/2 | 221/2 | 221/2 | 23 | 23 | 231/4 | 231/4 | 231/4 |
| NECK WIDTH | 13 | 13¾ | 13¾ | 14½ | 141/2 | 15 | 153/8 | 15¾ |
| SIDE LEG LENGTH | 381/4 | 38¾ | 38¾ | 39 | 391/2 | 391/2 | 39¾ | 39¾ |
| FRONT WAIST | | | | | | | | |
| LENGTH | 15¾ | 161/4 | 161/2 | 17 | 171/4 | 17¾ | 181/8 | 181/2 |
| BUST POINT | 91/8 | 91/2 | 91/8 | 101/4 | 10¾ | 111//8 | 111/2 | 117/8 |
| UPPER ARM | | | | | | | | |
| CIRCUMFERENCE | 91/8 | 101/4 | 10¾ | 111/8 | 111/2 | 1111//8 | 121/4 | 12¾ |
| | | | | | | | | |


WOMEN'S SIZE CHART (Tall) inches

* These sizes are Burda tall sizes and differ in height from the regular sizes. The height measurement is 69¼ inches and up. If you are shorter than 69¼ inches, you can make alterations to the length of the garment, the sleeve length, etc. to fit your measurements.


| BURDA SIZE | 64 | 68 | 72 | 76 | 80 | 84 | 88 | 92 |
|-----------------|-------|-------|-------|--------|-------|--------|-------|-------|
| HEIGHT | 691/4 | 691/4 | 691/4 | 691/4 | 691/4 | 691/4 | 691/4 | 691/4 |
| BUST | 30 | 311/2 | 33 | 34¾ | 361/4 | 37¾ | 391/2 | 41 |
| WAIST | 23 | 241/2 | 26 | 27¾ | 291/4 | 30¾ | 321/2 | 34 |
| HIP | 321/2 | 34 | 351/2 | 37 | 38¾ | 401/4 | 41¾ | 431/2 |
| BACK LENGTH | 161/2 | 16¾ | 17 | 171//8 | 171/4 | 171/2 | 17¾ | 18 |
| SLEEVE LENGTH | 24 | 24 | 24 | 241/2 | 241/2 | 24¾ | 24¾ | 24¾ |
| NECK WIDTH | 13 | 13¾ | 13¾ | 141/8 | 141/2 | 15 | 15¾ | 15¾ |
| SIDE LEG LENGTH | 411/2 | 41¾ | 41¾ | 421/4 | 421/2 | 421/2 | 43 | 43 |
| FRONT WAIST | | | | | | | | |
| LENGTH | 171/4 | 17¾ | 181/8 | 181/2 | 19 | 191/4 | 19¾ | 201/4 |
| BUST POINT | 97/8 | 101/4 | 10¾ | 111//8 | 111/2 | 111//8 | 121/4 | 12¾ |
| UPPER ARM | | | | | | | | |
| CIRCUMFERENCE | 91/8 | 101/4 | 10¾ | 111//8 | 111/2 | 111//8 | 121/4 | 12¾ |


burda Download-Schnitt

Modell 107 Burda Style 02/2011



Copyright 2011 by Verlag Aenne Burda GmbH & Co. KG, Am Kestendamm 1, D–77652 Offenburg Sämtliche Modelle, Schnittteile und Zeichnungen stehen unter Urheberschutz, gewerbliches Nacharbeiten ist untersagt. Der Verlag haftet nicht für Schäden, die durch unsachgemäße Handhabung des Schnitts, der Materialien, unsachgemäße Ausführung der Tipps und Anleitungen oder unsachgemäße Nutzung der Modelle entstehen.







1c



vordere Mitte Stoffbruch Fadenlauf center front fold straight grain ЛИНИЯ СЕРЕДИНЫ ПЕРЕДА СГИБ ДОЛЕВАЯ НИТЬ


vordere Mitte Stoffbruch Fadenlauf center front fold straight grain ЛИНИЯ СЕРЕДИНЫ ПЕРЕДА СГИБ ДОЛЕВАЯ НИТЬ


44


top BBEPXY

Taille / waist

1d









30

Reißverschluss zipper ЗАСТЕЖКА- МОЛНИЯ

N N


straight grain ДОЛЕВАЯ НИТЬ


Fadenlauf


.




4e











5c **N**

Fadenlauf straight grain ДОЛЕВАЯ НИТЬ 5d



