

## 07/2011 Satin trousers

By: burda style magazine

<http://www.burdastyle.com/projects/072011-satin-trousers>

---



Satin trousers burda style magazine patterns FAQ

## Materials

Crpe satin

---

### Step 1 — Preparation

Trace the pattern pieces from the pattern sheet. Glue pattern pieces 21 and 21a and pieces 23 and 23a together on the joining lines. Trace the pocket piece marked on piece 22 to the abutting line.


The stitching line at the zip opening is marked for size 76. For sizes 80 — 92, mark the stitching line the same distance from centre front as for size 76, noting length of opening. The pocket lines on piece 23 are marked in full for size 76 only. For sizes 80 — 92, complete the pocket lines accordingly.

Seam and hem allowances:

Seams and edges 1.5 cm (5/8 in). Turn-up and hem allowance are already included on the pattern pieces.

---

### Step 2 — Cutting out



21 front trouser piece 2x

22 side hip yoke with

— integrated pocket piece 2x

— — pocket piece 2x

23 back trouser piece 2x

a) 2 waistband pieces with 6 cm (23/8 in) overlap and with 6 cm (23/8 in) underlap, 43 — 45 — 47 — 49 — 51 cm (17 — 173/4 — 181/2 — 191/4 — 201/2 ins) long, 7 cm (3 ins) wide,

finished width 3.5 cm (1 1/2 ins),

b) 2 pocket pieces (back pocket),

15 cm (6 ins) wide, 15 cm (6 ins) long (incl. allowances),

c) welt (back pocket), 15 cm (6 ins) long, 6 cm (2 3/8 ins) wide (incl. allowances),

d) left underlap, 19 cm (7 1/2 ins) long, 21 cm (8 3/8 ins) wide (incl. allowances),  
19 cm (7 1/2 ins) long, 7 cm (3 ins) wide, finished width 3.5 cm (1 1/2 ins).

View A: Use the matte side as the right side of the fabric.

Interfacing: See pattern layout. Iron a strip of interfacing, 4 cm (1 5/8 ins) wide, to wrong side of right back trouser piece, over pocket marking. Iron Vilene Bias Tape/stay tape to pocket opening edges of front trouser pieces.

---

### Step 3 — Darts

Fold front trouser pieces lengthwise, with wrong side facing in, and press the creases, ending approx.

15 cm (6 ins) above lower edge. Stitch back darts and press toward centre. Stitch front darts at a long stitch setting. Press darts toward centre. Undo stitching. Baste pressed darts to upper edge. Fold pleats in direction of arrows and baste.

---

### Step 4 — Hip yoke pockets

Stitch pocket pieces right sides together with pocket opening edges of front trouser pieces. Turn pocket pieces up and stitch to seam allowances, close to seam. Turn pocket pieces to inside. Pin pocket opening edges to side hip yokes, at abutting lines. Stitch pocket edges together. Baste pocket pieces to wrong side of front trouser pieces, first trimming away allowance of right pocket piece along centre front. Stitch bottom ends of pocket openings to hip yokes, approx. 3 cm (1 1/4 ins) long.

---

### Step 5 — Sew single welt pocket

Sew single welt pocket on right back trouser: Mark an abutting line for welt, 1.5 cm (5/8 in) from welt joining line (= finished width of welt). Fold welt lengthwise, right side facing out, and press. Baste folded welt over welt joining line so that fold edge of welt meets abutting line and open lengthwise edges lie between pocket lines. Stitch welt in place along joining line. Stitch one pocket piece along pocket joining line. Slash between lines of stitching and clip diagonally toward each last stitch, not cutting into welt or pocket piece. Turn welt into pocket opening and pull pocket piece to inside. Stitch second pocket piece to seam allowances of welt joining seam. Fold small triangles at pocket opening ends to inside and stitch to welt and pocket pieces, from seam end to seam end. Trim pocket pieces even and stitch together.

---

### Step 6 — Leg seams

Stitch side seams and inside leg seams. Press seam allowances open. Stitch centre front seam from slit mark to inside leg seam

---

### Step 7 — Zip opening

Press self-facings to inside, along centre front on the right and 5 mm (3/16 in) before centre front on the left. Stitch zip under left edge of opening (underlap), stitching close to teeth of zip. Pin opening closed, matching centres. Stitch free zip tape to right facing, not catching trouser piece. Baste facing in place. Topstitch opening from upper edges to 3 cm (1 1/4 ins) before the end as marked. Fold underlap piece lengthwise and stitch across bottom end. Turn right side out. Lay underlap under left edge of opening and pin to facing.

Stitch facing to underlap, close to zip joining seam. Lay opening closed again and topstitch to the end, catching underlap.

---

## **Step 8 — Waistband and centre back seam**

Stitch waistband pieces to upper edges of trousers, leave right end of waistband extending from centre front. Stitch left end of waistband to underlap, leaving remainder extending. Press allowances of joining seams onto waistband. Stitch centre back seam on trousers and waistband. Press seam open, from upper edge to beginning of curve. Do not press allowances flat along curve. Fold waistband lengthwise, with right side facing in. On overlap and underlap, turn allowances of joining seam down again and stitch along lower edges of overlap and underlap and across front ends of waistband. Trim seam allowances, trimming corners diagonally. Turn waistband right side out. Turn in inside edge and baste over joining seam. Work from right side to stitch in line of seam. Sew trousers fastener to waistband. Work buttonhole in left end of waistband, for inside button.

---

## **Step 9 — Turn-ups**

Press trouser legs to inside on turn-up fold line. Machine stitch or sew in place by hand. Fold lower edges of trouser legs up, 4.5 cm (17/8 ins) wide, and press. Sew upper edges of turn-ups in place, loosely by hand, approx. 1.5 cm (5/8 in) below pressed fold. Press creases on back trouser pieces. Press remaining front creases.

---

**BurdaStyle**

07/2011 Satin trousers