

5/2010 Harem Trousers

By: burda style magazine


<http://www.burdastyle.com/projects/52010-harem-trousers>

Harem Trousers burda style magazine patterns FAQ

Materials

Crpe

Step 1 — Preparation



116 36-44


Trace pattern pieces from pattern sheet. Lengthen piece 21 as indicated. Trace pocket piece from piece 21 as separate pattern piece — the same for all sizes.

The stitching line at the zip fly opening is marked for size 36. For sizes 38 — 44, mark the stitching line the same distance from centre front as for size 36.

Seam and hem allowances:

Seams and edges 1.5 cm (5/8 in), hem 5 cm (2 ins).

Step 2 — Cutting Out



21 front trouser piece 2x

22 pocket piece 4x

23 back trouser piece 2x

a) right facing piece, 13 cm (5 1/4 ins) long, 3 cm (1 1/4 ins) wide,

b) left underlap piece 13 cm (5 1/4 ins) long, 6 cm (2 1/2 ins) wide, finished width 3 cm (1 1/4 ins),

c) welt strip for pocket, 13 cm (5 1/4 ins) long, 5 cm (2 ins) wide (incl. allow.),

d) 2 pocket pieces (back pocket), 13 cm (5 1/4 ins) wide, 13 cm (5 1/4 ins) long (incl. allowance),

e) waistband with 3.5 cm (1 1/2 in) underlap, 76.5 — 80.5 — 84.5 — 88.5 — 92.5 cm (30 1/4 — 31 3/4 — 33 1/4 — 34 7/8 — 36 1/2 ins) long, 8 cm (3 1/4 ins) wide, finish-ed width 4 cm (1 5/8 ins),

f) 4 belt carriers, a total of 48 cm (19 ins) long, 6 cm (2 3/8 ins) wide (incl. allow.).

Interfacing: See pattern layout. Iron a strip of interfacing, 4 cm (1 5/8 ins) -wide, to wrong side of right back trouser piece, over pocket marking.

Step 3 — Darts and pleats

Stitch back darts and press toward centre. Work from inside to stitch pleats in front trouser pieces, from upper edge to arrow mark. Fold pleats in arrow direction and press. Baste to upper edge.

Step 4 — Construct single welt pocket on right back trouser piece

Mark an abutting line for the welt, 1.5 cm (5/8 in) from welt joining line (finished width of welt). Fold welt strip lengthwise, right side facing out, and press. Baste doubled welt strip over welt joining line so that fold edge of welt meets abutting line and open lengthwise edges lie between pocket lines. Stitch welt in place

along welt joining line. Stitch one pocket piece to pocket piece joining line. Slash between lines of stitching and clip diagonally toward each last stitch. Do not cut into piping or pocket piece. Lay welt toward pocket opening and pull pocket piece to inside. Stitch other pocket piece to seam allowances of welt joining seam. Fold small triangles at pocket opening ends to -inside and stitch to welt and pocket pieces, from seam end to seam end. Trim pocket pieces even and stitch together.

Step 5 — Side seams

Stitch side seams, not stitching across pocket openings

Step 6 — In-seam pockets

Work from the inside to pin pocket pieces right sides together with seam allowances of pocket opening edges and stitch in place, directly along marked seam lines. -Stitch pocket pieces close to -seam, above and below pocket openings. Press pocket pieces forward and -stitch together. Baste upper edges of pocket pieces in place.

Step 7 — Centre front seam

Stitch centre front seam below slit mark.

Step 8 — Zip opening

Stitch right facing piece right sides together with right edge of opening. Turn facing to inside and press edge. Press allowance on left edge of opening (underlap) to inside, 5 mm (3/16 in) before centre front, and understitch zip close to teeth of zip. Pin opening closed matching centres. Stitch loose zip tape to right facing, not catching trouser piece. Baste facing in place. Topstitch opening as marked and again 7 mm (1/4 in) wide. Fold underlap piece lengthwise. Stitch across bottom end. Turn right side out. Lay underlap under left edge of opening and pin to allowance of opening edge. Stitch allowance of opening edge to underlap, close to zip joining seam. Close zip. Topstitch to end of opening, catching underlap.

Step 9 — Centre back seam

Stitch centre back seam. Stitch inside leg seams as continuous seams

Step 10 — Belt carriers

Fold strip for belt carriers length-wise, right side facing in. Stitch 2 cm (3/4 in) from fold edge. Turn right side out. Topstitch close to edge. Cut into 4 -pieces. Baste belt carriers to upper edge of trousers: one next to each pleat in front and centred between each side seam and centre back, in back.

Step 11 — Waistband

Stitch waistband to upper edge of trousers, stitching waistband underlap to underlap of opening edge. Press allowances onto waistband. Fold waistband in half lengthwise, right side facing in. Lay allowance at inside edge of waistband up at ends. Stitch across ends of waistband. Turn waistband right side out. Turn in inside edge, baste about 5 cm (2 ins) long, then lay flat over joining seam. Topstitch waistband close to all edges. Work buttonhole in right end of waistband.

Step 12 — Stitching belt carriers to waistband

Stitch across belt carriers, 2 cm (3/4 in) below waistband joining seam. Lay belt carriers up, turn ends in and stitch to upper edge of waistband.

Step 13 — Hem

Press hem allowances to inside and stitch 4 cm (15/8 ins) wide.

BurdaStyle

5/2010 Harem Trousers